

# **LogPage Manual**



**WiPath Communications Ltd**

# Contents at a Glance

Contents.....	3
Introduction.....	9
Setup.....	15
Starting Application.....	17
Main Program.....	20
System Settings.....	36
User Accounts.....	57
Filters.....	61
Channels.....	78
Alarms.....	80
Reports.....	90
Alerts.....	105
Grids.....	117
Demo.....	125
Shortcuts.....	127

# Contents

Contents at a Glance.....	2
Introduction.....	9
LogPage and Interceptor.....	9
Capcode Filter Criteria.....	9
Text Filter Criteria.....	9
Capcode And Text Filter Criteria.....	9
Watchdog Alarms.....	10
Reports .....	10
LogPage/Interceptor Server.....	11
Description.....	11
Running Server.....	11
Connecting Client.....	11
Disconnecting Client.....	12
Broken Connection.....	12
Stopping Server.....	12
LogPage/Interceptor Client.....	13
Description.....	13
Running Client.....	13
Connecting to Server.....	13
Stopping Client.....	13
Connection Error Log.....	14
Setup.....	15
Requirements.....	15
Installation.....	15
Registration.....	15
Starting Application.....	17
Start Up.....	17
Database Error.....	17
Log In.....	18
Quick Log In.....	18
Log in as a different user.....	19
Main Program.....	20
Main Form.....	20
Toolbar.....	20
Status Bar.....	21
Full Message View.....	23
Help Hints.....	23
Changing Window State.....	24
Messages.....	25
Clear Displayed Messages.....	25
Delete All Messages Permanently.....	25
Delete Old Messages Permanently.....	25
Refresh Display.....	26
Copy Selected Message.....	26
Moving Through Displayed Messages.....	26
Running Channels.....	28
Turning Channel On/Off.....	28
Turning Filters On/Off.....	29

Turning Alarm On/Off.....	29
Running LogPage/Interceptor.....	30
Run.....	30
Auto Run.....	30
Run Demo.....	30
Pause.....	30
Stop.....	31
Hardware Settings.....	32
Comm Port.....	32
Baud Rate.....	32
Upload ROM File (Interceptor Only).....	33
Set Channels Hardware (Interceptor Only).....	33
Log Viewer.....	34
Open Alarm Log Viewer.....	35
Open Error Log Viewer.....	35
System Settings.....	36
Set System.....	36
Save System Settings.....	36
Cancel Changes.....	36
Set Default Colours.....	37
Set Messages.....	38
Display Number.....	38
Message Buffers.....	38
Delete Old Messages.....	39
Set Message Display.....	40
Set i-Page Server.....	41
Selecting i-Page Server.....	41
Local i-Page Server.....	42
Remote i-Page Server.....	42
Set Email.....	43
SMTP.....	43
Client Settings.....	44
Testing Email Settings.....	44
Set Paging.....	46
Carrier Settings.....	46
Testing Pager Settings.....	47
Set SMS.....	49
Settings.....	50
Other Settings.....	50
Testing SMS Settings.....	50
Set Alarm Log .....	51
Alarm Log Settings.....	51
Log Display Settings.....	52
Set TCP Server.....	53
Host.....	53
Port.....	53
Client Buffer Size.....	54
Keep Alive Timeout.....	54
Set TCP Client.....	55
Host.....	55
Port.....	55
Reconnect Timeout.....	55

Connection Error Log.....	56
User Accounts.....	57
New User.....	57
Edit User.....	58
Change User's Password.....	58
Save User.....	58
Delete User.....	59
Cancel Changes.....	59
Edit Personal Account.....	60
Change Personal Password.....	60
Filters.....	61
Set Filter.....	61
Edit Filter Dialog Layout.....	61
New Filter.....	62
New Filter From Message.....	62
Edit Filter.....	63
Selecting Filter for Editing.....	63
Selected Filter.....	63
Filter Colours.....	64
Sound Alert.....	65
Send Pager Message.....	66
Send Email Message.....	66
Send SMS Message.....	66
Filter Traffic Monitor.....	67
Edit Message.....	69
Popup Alert.....	71
Set Channels.....	71
Filter Summary.....	71
Set Grid.....	72
Save Filter.....	72
Delete Filter.....	72
Cancel Changes.....	72
Capcode Filter Type.....	73
Text Filter Type.....	73
Combo Filter Type.....	74
Export Filters.....	75
Import Filters.....	76
View Filter Info.....	77
Channels.....	78
Set Channel.....	78
Edit Channel.....	78
Setting the Watchdog Alarm.....	78
Changing Channel Setups - Interceptor Only.....	79
Alarms.....	80
Set Watchdog Alarm.....	80
Edit Alarm Dialog Layout.....	81
New Alarm.....	82
Edit Alarm.....	82
Selecting Alarm for Editing.....	82
Selected Alarm.....	83
Alarm Sound.....	85
Send Page Message.....	86

Send Email Message.....	86
Send SMS Message.....	86
Alarm Popup Form.....	86
Alarm Summary.....	87
Alarm Display.....	88
Set Grid.....	89
Save Alarm.....	89
Cancel Changes.....	89
Reports.....	90
Using Report Tool.....	90
Closing Report Tool.....	91
Set Report.....	92
Edit Report Dialog Layout.....	92
New Report.....	93
Edit Report.....	93
Basic Settings.....	94
Report Filter.....	96
Colours.....	97
Email.....	97
Channels.....	98
Report Summary.....	99
Run.....	99
Report Window.....	99
Set Grid.....	99
Save Report.....	100
Delete Report.....	100
Cancel Changes.....	100
Run Report.....	100
Export Report To File.....	100
Report Window.....	102
Arranging Reports.....	103
Set Report Window.....	103
Sorting Displayed Report.....	104
Alerts.....	105
Popup Alert.....	105
Enable Popup Alert.....	105
Show On Option (Filter Only).....	106
Popup Form Caption.....	106
Popup Dimensions.....	106
Popup Colour.....	106
Popup Font.....	106
Flashing.....	107
Timeout.....	107
Message.....	107
Testing.....	107
Save Popup.....	108
Cancel Changes.....	108
Pager Message.....	109
Email Message.....	111
SMS Message.....	113
Set Alert Message.....	115
Grids.....	117

Set Grid.....	117
New Field (Column).....	118
Edit Field.....	119
Changing field position.....	119
Changing field title.....	119
Showing/Hiding Fields.....	119
Changing Field Width.....	120
Changing Display Data Type.....	120
Save Field.....	120
Delete Field.....	120
Grid Display.....	121
Grid Default Colour.....	121
Use Grid Colours Only.....	121
Word Wrap.....	121
Grid Font.....	121
Vertical Margins.....	122
Save Grid Display.....	122
Cancel Changes.....	122
Quick Setup.....	122
Displaying/Hiding Columns.....	122
Resizing Columns.....	123
Changing Column Position.....	123
Sorting Grid.....	123
Demo.....	125
Set Demo.....	125
Save Demo.....	126
Cancel Changes.....	126
Shortcuts.....	127

# Introduction

## LogPage and Interceptor

LogPage and Interceptor are Windows based applications used to log message traffic over a Pocsag or Flex paging network directly to a PC or computer network.

LogPage is designed to work with the PDT2000 Paging Data Terminal or PDR2000 Paging Data Receiver to monitor a single channel.

Interceptor combines with the Interceptor 4 channel receiver system to monitor up to 4 paging frequencies within up to 4 pre-selected frequency bands. Pocsag and Flex may be monitored on separate channels using Interceptor.

Both applications are equipped with powerful filtering and reporting tools that enable the user to automatically search through received page messages using different criteria and output the filtered results to the screen or via email as an automatic report.

### Capcode Filter Criteria

- Find all messages sent to a specified capcode
- Find all messages sent to a specified range of capcodes
- Find all messages sent to any capcode greater than a specified value
- Find all messages sent to any capcode less than a specified value

### Text Filter Criteria

The user can define a word, a phrase or a group of unrelated words

- Find all messages that contains a word, phrase or group of words or text.
- Find all messages that contains a group of words or text in any order
- Find all messages that contains a group of words or text in a specified order
- All searches can be defined as case sensitive or case insensitive
- All searches can be defined as searches for partial word match or searches for the whole word only

### Capcode And Text Filter Criteria

Capcode and text filter criteria can be combined together in a single search, and the user has option to combine them in three different ways:

- Find all messages that match both capcode and text criteria
- Find all messages that match either capcode or text or both
- Find all messages that match either capcode or text but not both

An unlimited number of search filters can be set up and each filter can be displayed in a different way (different background and text colour), can raise a visual and/or audible alert and can be re-sent



as a page message, email message or text message to an unlimited number of pagers, email addresses and of mobile phones.

## **Watchdog Alarms**

Both applications can have Watchdog Alarms set up which monitor the watchdog messages sent out on most paging networks (messages sent on a regular interval to a specific capcode) to detect failure of the network or transmitter. On detection of a watchdog failure audible and visual alarms can be raised as well as messages sent to pagers, email addresses and mobile phones.

## **Reports**

A powerful and easy to use reporting engine is included in both LogPage and Interceptor to enable the develop customized reports of message traffic based on the stored message database.

The user can set multiple criteria for each report in a similar manner to the filtering criteria.

Each report can be stored as a report template and re-used many times.

The results of each report query may be displayed on screen and can be saved as a CSV file which can be opened and analysed in a spreadsheet program.

The user can also set the program to run reports automatically at certain time intervals (days or hours) and send the results as attached CSV files by email to an unlimited number of email addresses.

Both applications come in three flavours: **standalone**, [server](#) and [client](#).

## LogPage/Interceptor Server

### Description

LogPage/Interceptor Server has all functionality of the standalone application. In addition it is capable to connect through the TCP/IP connection to unlimited number of clients and feed them with data that it receives from the hardware device.

To accomplish that it creates a TCP port that enables clients to connect to it. For every client that requests a connection, the server creates:

- ✓ New connection
- ✓ Memory buffer to store data while waiting to send them to the client
- ✓ Separate thread of execution, to avoid interference with other server functionality

The server also handles the authentication process for its clients.

While dispatching messages to its client, the server is able also to perform:

- Displaying messages
- Message filtering
- Storing messages into the file
- Raising watchdog alarm
- Running reports

If you are using the server only to send messages to the clients and want to save some computer resources, just turn channel(s) on the server off.

### Running Server

Before running the server, you need to set some values, specific for the server application. (see [Set Tcp Server](#)).

To run the server, use the same commands as for running the standalone application (see [Running LogPage/Interceptor](#)).

When the server runs, it connects to the hardware device, and waits for the clients.

For a testing purpose, you can also run the server in a demo mode and the server will send demo messages to its clients.

### Connecting Client

When a client asks for a connection, the server requests it to pass through the [authentication procedure](#). If the authentication procedure is unsuccessful, the client is disconnected.

The server maintains data about all successfully connected clients for the duration of the server application. Data are not stored permanently.

## Disconnecting Client

When the client disconnects, it is marked as inactive and logged out of the system. That means that the next time the client ask for the connection it will have to pass the authentication procedure again.

To speed up future connections data about the client are maintained in the server memory. To conserve resources, its buffers and thread are destroyed.

## Broken Connection

When the connection to the client is broken, the server will carry out the same procedure as with the disconnection, but it will not log the client out of the system. So, when the client manages to fix the connection it will not be required to pass the authentication.

## Stopping Server

To stop the server, use the same commands as for stopping the standalone application (see [Running LogPage/Interceptor](#)).

The server will carry out the disconnect procedure for all the clients. Before disconnecting, it will send a warning message to all its clients.

## LogPage/Interceptor Client

### Description

LogPage/Interceptor Client has almost all functionality of the standalone application. It is also capable to connect through the TCP/IP connection to the designated server and receive message data from it.

Differences:

- ✗ Cannot connect directly to the hardware device (tools for setting hardware connection missing)
- ✗ Data about users maintained on the server (all user settings tools disabled)
- ✗ Cannot run a demo application (all demo engine tools disabled)

After receiving messages from the server, the client is also able to perform:

- Displaying messages
- Message filtering
- Storing messages into the file
- Raising watchdog alarm
- Running reports

### Running Client

Before running the client, you need to set some values, specific for the client application. (see [Set Tcp Client](#)).

To run the client, use the same commands as for running the standalone application (see [Running LogPage/Interceptor](#)).

When the client runs, it attempts to connect to the server.

### Connecting to Server

When a client asks for the connection, the server requests the [authentication](#). If the authentication procedure is successful, the client automatically starts receiving messages.

It is the client responsibility to maintain its connection to the server. That is why the client regularly checks for the state of the connection. If the client concludes that the connection is broken it will start a reconnect procedure.

### Stopping Client

To stop the client, use the same commands as for stopping the standalone application (see [Running LogPage/Interceptor](#)).

The client will send an appropriate message to the server to let it know that the client is terminating its connection. After that the client will disconnect from the server.

When the client disconnects in that way from the server, it will be logged out of the system. That means that the next time the client ask for the connection it will have to pass the [authentication procedure](#) again.

## **Connection Error Log**

Besides that, the Client application maintains an connection error log, to help the user to troubleshoot connection problems.

This log can be found in the “<Install\_directory>\LogPage Client\Logs” folder under the name “IPErrorLogXX.txt” (‘XX’ denotes a file number).

To see that file while the client is running, see “[Open Error Log Viewer](#)”.

# Setup

## Requirements

**Operating System:** Windows NT / 2000 / XP / Vista / Windows 7 / Windows 8 / Windows 10

**Disc Space:** 20 MB

**Hardware:**

- ✓ PDT3000 Paging Data Terminal or PDR3000 Paging Data Receiver (for LogPage standalone and server)
- ✓ Interceptor 4 channel receiver system (for Interceptor standalone and server)

**Software:** i-Page Server software (installed by the installer)

## Installation

To install or uninstall LogPage/Interceptor you must have administrator privileges on the local machine.

Setup programs for all versions of LogPage/Interceptor run in the administrator mode, so you must be logged on as a local machine administrator.

After installation, all programs also run in the administrator mode.

### LogPage/Interceptor NA (No admin)

1. Log on to the machine as the computer administrator.
2. Run the installation program.
3. Run LogPage/Interceptor NA for the first time as an administrator.
4. Find the folder that LogPage/Interceptor is installed in. (default - "C:\Program Files\LogPage")
5. Give any restricted user that will use the application permission to write to that folder<sup>1</sup>.

The user should have following rights for the LogPage/Interceptor folder:

- ✓ Read & Execute
- ✓ List Folder Contents
- ✓ Read
- ✓ Write

---

1) For power users and administrators step 5 is not necessary, because they already have these rights

## Registration

To enter the registration data and to register LogPage/Interceptor you must be logged on to the machine as an administrator.

The application is registered per machine and the registration is valid for any user that can log on to that computer.

**LogPage - Registration**

**LogPage**  
Version: 3.2.4.4  
Copyright © WiPath Communications Ltd  
<http://www.wipath.com>

**Registration**  
Trial Version      You have 29 days left

User Name:  
John Lock

Company:  
Lightning Ltd

Email:  
john@blog.com

License Key:  
847BF-F95F2-1C4C4-AEC8B

Registration Key:  
F8A50-84266-E1216-CEC2B

Email   Register   Close

# Starting Application

## Start Up


During the start up, the application will check some basic settings and you will be required to log in. If the application does not find all necessary files, you will get an error message.

## Database Error

If you have deleted the database or moved its file to another folder, You will get the 'Database error message'. The message will offer you the choice to find the correct database file.

If you answer 'Yes', you will get a dialog box, which will help you to find the database.

If you answer 'No', the application will terminate.



Click on the 'Find' button to open the 'Find File' dialog.

In the dialog's title you will see the name of the database file that system is expecting to find. Find that file and click the 'Open' button to return to the previous dialog.

Select the 'Connect' button. If you get the 'Success' message, just click on the 'OK' button to continue with loading of the application. Otherwise, try to find another file.



## Log In

Before it starts, LogPage/Interceptor will require from the user to complete the authentication process.



- ✓ Enter your user name in the “User Name” control – **not case sensitive**
- ✓ Enter your password in the “Password” control – **case sensitive**
- ✓ Press the “Log In” button or the Enter key.

If the login procedure is not successful, the application displays an error message and the remaining number of trials allowed. Current default is three unsuccessful trials, before the application terminates.

After you log into the LogPage/Interceptor, the system will set all permissions according to the account permissions, set by the administrator.

Default login for the administrator:

- ➔ **User Name:** *admin*
- ➔ **Password:** *admin*

Default login data for other users are assigned by the administrator.

It is strongly recommended that you change your password as soon as you log into the system for the first time.

LogPage/Interceptor [Client](#) application does not require authentication on start up. You will be asked to log in after you select one of the "[Run](#)" commands and the client successfully connects to the LogPage/Interceptor [Server](#).


## Quick Log In

If you always use LogPage/Interceptor as an administrator, you can bypass the login procedure by un-checking “File|Use Login” menu item<sup>1</sup>. If this menu item is not checked, the program will

---

1) This feature is not available in the LogPage/Interceptor [Client](#) application.

bypass authentication on start up and log the user automatically as an administrator.



If only one person will be using LogPage/Interceptor on a particular computer, the “Remember Me<sup>2</sup>” check box on the “Login” dialog may be checked after entering the user name and password. Next time when you start the application, your login data will be already entered and all you need to do is to select the “Log In” button or press the “Enter” key.

The system can remember only one user at the time, so the last one will overwrite the previous. All authentication data is stored in a secure way.

This feature is available in all versions of LogPage/Interceptor.

**Warning:** Be aware that both “Quick Log In” procedures pose a security risk.

### Log in as a different user

Select ‘File|Log Off<sup>3</sup> <userName>’

Shortcut: **Ctrl+Q**

Hot Keys: **Alt+F,L**

Any of commands above will start a new login procedure, where you can login as a different user.

---

2) This feature is available in all versions of LogPage/Interceptor.

3) This feature is not available in the LogPage/Interceptor [Client](#) application

# Main Program

## Main Form



## Toolbar

The main toolbar contains buttons<sup>1</sup> that are associated with commands that are used more often. Each button has an icon that indicates its function.

If you are not sure what is a button for, hover the mouse over the button and a description (and keyboard shortcut) will pop up. You will also see a description of its functionality displayed in the first panel of the main status bar.

1) Depending on the user's permissions, some of the buttons may be disabled

## LogPage Toolbar



## Interceptor Toolbar



### Showing/hiding Toolbar

You can select to show or hide the main toolbar. Use one of the following toggle commands:

Select **‘View|Toolbar’** – if shown, a check mark appears on the menu


Shortcut: **Shift+Ctrl+T**

Hot Keys: **Alt+V,T**






If the main toolbar is displayed, the above commands will hide it and vice versa.

## Status Bar

The main status bar consists of 4 fields. Their usage depends on the flavour of the LogPage/Interceptor application you are running.



Field	Display
<b>First field</b>	Longer version of hints, when the mouse moves over toolbar buttons or menu items
	LogPage/Interceptor system messages
	Email subsystem messages
	Pager subsystem messages
	SMS subsystem messages
	Connection results (Client and Server only)
	Some non-critical errors

<b>Second field</b>		Watchdog alarm status  Format: "Alarm on: Channel <channel_no>,<channel_no>,<channel_no>, etc. e.g. "Alarm on: Channel 1,3,4"
<b>Third field<sup>2</sup></b>		Connections
	<a href="#">Client</a>	Shows the status of the connection to the server  Format: "Connected to <server_IP_address>:<port_no> e.g. "Connected to 127.0.0.1:6001"
	<a href="#">Server</a>	Shows the number of clients currently connected to the server  e.g. "3 clients connected"
<b>Fourth field<sup>3</sup></b>		Connection icons
	<a href="#">Client</a>	 Connected to Server  Not connected to Server
	<a href="#">Server</a>	 Server not running and no clients connected  Server running but no clients connected  Server running and at least one client connected

In the LogPage/Interceptor [Server](#) application, right-clicking on the third or fourth field will invoke a popup menu with the names of clients logged into the server.



Clicking on any of the names will bring a dialog with basic information about the selected client.

2) It is not used in the standalone application and it is used differently in the Client and Server applications

3) It is not used in the standalone application and it is used differently in the Client and Server applications



### ***Showing/hiding Status Bar***

You can select to show or hide the main status bar. Use one of the following toggle commands:

Select '**View|Status Bar**' – if shown, a check mark appears on the menu

Shortcut: **Shift+Ctrl+S**

Hot Keys: **Alt+V,S**

If the main status bar is displayed, the above commands will hide it and vice versa.

### **Full Message View**

The full message view is a control at the bottom of the application that displays the full text of any selected message.

The chatter, the bustle, the noise died suddenly as the people in front spotted the hanging cat. **Harry, Ron, and Hermione** stood alone, in the middle of the corridor, as silence fell among the mass of students pressing forward to see the grisly sight.

### ***Showing/hiding Full Message View***

You can select to show or hide the full message view. Use one of the following toggle commands:

Select '**View|Show Full Message**' – if shown, a check mark appears on the menu

Shortcut: **Shift+Ctrl+M**

Hot Keys: **Alt+V,M**

If the full message view is displayed, the above commands will hide it and vice versa.

To change font and colour settings of the full message view, see [Set Message Display](#).

### **Help Hints**

When you position your mouse over any of the toolbar buttons, a tool tip with the button name and its keyboard shortcut appears.

When you position your mouse over any of the toolbar buttons, main menu or popup menu item, description of its functionality appears in the first panel of the main status bar.


### **Showing/hiding Help Hints<sup>4</sup>**

To show help hints, select '**Help|Hints On**'.

Hot Keys: **Alt+H,N**

To hide tool tips, select '**Help|Hints Off**'.

Hot Keys: **Alt+H,O**



A check mark appears next to the currently selected option.

### **Changing Window State**

You can toggle between **normal screen** and **full screen**.

#### **Full Screen**

Select '**View|Full Screen**'

Shortcut: **Ctrl+PageUp**

Hot Keys: **Alt+V,F**

You can also use standard Windows 'Maximize' command.

All above commands are available only when the program runs in a normal screen mode.

#### **Normal Screen**

Select '**View|Normal Screen**'

Shortcut: **Ctrl+PageDown**

Hot Keys: **Alt+V,N**

You can also use standard Windows 'Restore' command.

All above commands are available only when the program runs in a full screen mode.










---

4) Turning the help hints on/off does not affect displaying of the description of the commands in the main status bar.  
This functionality cannot be turned off.

## Messages

All messages are stored in the database in the form received from the Receiver Hardware. Filtering results and formatting data are not stored with them.

Whenever the application starts it loads and displays stored messages up to the number of displayed messages set by the user ( see [Set Messages](#)). Displayed messages will be filtered and formatted according to the current filter settings.

	Next Row	Down
	Previous Row	Up
	First Row	Home
	Last Row	End
<hr/>		
	Clear Display	Ctrl+F2
	Delete All Messages	Shift+Ctrl+Del
	Delete Old Messages	Ctrl+Del
	Refresh Display	Ctrl+F3
	Copy Selected Message	Shift+Ctrl+C

### Clear Displayed Messages

To delete all displayed messages select '**Messages|Clear Display**'.

Shortcut: **Ctrl+F2**

Hot Keys: **Alt+M,C**

This will only remove messages from the display grid, but will not delete messages from the database.

### Delete All Messages Permanently

To delete all messages from the database permanently select '**Messages|Delete All Messages**'

Shortcut: **Shift+Ctrl+Del**

Hot Keys: **Alt+M,A**

You will get a warning that all messages will be deleted permanently from the system and option to cancel the operation.

### Delete Old Messages Permanently

To delete old messages from the database permanently select '**Messages|Delete Old Messages**'. The system will delete messages according to the current settings on [Set Messages](#).

Shortcut: **Ctrl+Del**

Hot Keys: **Alt+M,O**



You will get a warning that messages older than your [set interval](#) will be deleted permanently from the system and option to cancel the operation.

## Refresh Display

This command will reload and redisplay stored messages from the database up to the number of displayed messages set by the user (see ). Displayed messages will be filtered and formatted according to the current filter settings.

Select **‘Messages|Refresh Display’**

Shortcut: **Ctrl+F3**

Hot Keys: **Alt+M,R**

## Copy Selected Message

To copy the whole content of the selected message to the system clipboard select **‘Messages|Copy Selected Message’**.

Shortcut: **Shift+Ctrl+C**

Hot Keys: **Alt+M,S**

The content of the message can be pasted from the clipboard to any text editing program.

## Moving Through Displayed Messages

To move to the next message, select **‘Messages|Next Row’**,

or click on the “Next Row” toolbar button 

Shortcut: **Down Arrow**

Hot Keys: **Alt+M,N**

To move to the previous message, select **‘Messages|Previous Row’**,

or click on the “Previous Row” toolbar button 

Shortcut: **Up Arrow**

Hot Keys: **Alt+M,P**

To move to the first message, select **‘Messages|First Row’**,

or click on the “First Row” toolbar button 

Shortcut: **Home**

Hot Keys: **Alt+M,F**

To move to the last message, select **‘Messages|Last Row’**,

or click on the “Last Row” toolbar button 

Shortcut: **End**

Hot Keys: **Alt+M,L**


All above commands are available only on the static grid if the logging of messages is paused or


stopped. If the logging is active those commands are disabled.

## Running Channels

All commands here are toggle commands. If the channel's feature is on, then its respective menu item has a check mark next to it. In that case using any of the commands will turn it off, and the other way around.

### Turning Channel On/Off


Channel button when the channel is **ON** 

Channel button when the channel is **OFF** 

#### Interceptor




Select '**Channels|Channel<1,2,3,4>|On**' (the number is a channel number)

Click on the "**Channel <1,2,3,4>**" button (the number is a channel number) 

Shortcuts: **Ctrl+1,2,3,4** (the number is a channel number)

Hot Keys: **Alt+C,1(2,3,4),O**

#### LogPage



Select '**Channel|On**'.

Click on the "**Channel 1**" button 

Shortcuts: **Ctrl+1**

Hot Keys: **Alt+C,O**

## Turning Filters On/Off

If you do not turn any of the filters on, the channel will not use them to filter messages.

<b>Interceptor</b>	<b>LogPage</b>
<b>Capcode Filter</b>	
<b>Channels Channel&lt;1,2,3,4&gt; Capcode Filter On</b>	<b>Channel Capcode Filter On</b>
Hot Keys: Alt+C,1(2,3,4),C	Hot Keys: Alt+C,C
<b>Text Filter</b>	
<b>Channels Channel&lt;1,2,3,4&gt; Text Filter On</b>	<b>Channel Text Filter On</b>
Hot Keys: Alt+C,1(2,3,4),T	Hot Keys: Alt+C,T
<b>Combo Filter</b>	
<b>Channels Channel&lt;1,2,3,4&gt; Combo Filter On</b>	<b>Channel Combo Filter On</b>
Alt+C,1(2,3,4),F	<b>Hot Keys: Alt+C,F</b>
<b>Show Filtered Only</b>	
<b>Channels Channel&lt;1,2,3,4&gt;  Show Filtered Only</b>	<b>Channel Show Filtered Only</b>
Hot Keys: Alt+C,1(2,3,4),W	Hot Keys: Alt+C,W

If you do turn 'Show Filtered Only' on, only filtered messages for that channel will be displayed.

## Turning Alarm On/Off


<b>Interceptor</b>	<b>LogPage</b>
<b>Channels Channel&lt;1,2,3,4&gt; Alarm On</b>	<b>Channel Alarm On</b>
Hot Keys: Alt+C,1(2,3,4),A	Hot Keys: Alt+C,A

## Running LogPage/Interceptor

### Run

To start logging page messages from the Receiver Hardware, use one of the following commands:

Select **'Run|Run'**

Click on the **"Run"** toolbar button 

Shortcut Key: **F5**

Hot Keys: **Alt+R,R**

In the LogPage/Interceptor Client application the above commands will result in the client attempting to connect to the server. If the connection is successful, the user will be asked to [log into](#) the server. After successful authentication the client will immediately start receiving pager messages (through TCP/IP connection) from the server.

### Auto Run

To start logging page messages from the Receiver Hardware as soon as the program starts,

Select **'Run|Auto Run'**<sup>5</sup>

Hot Keys: **Alt+R,A**

If the auto-run feature is on, a check mark will appear in front of its menu item.

### Run Demo

To start logging demo page messages from the file, use one of the following commands:

Select **'Run|Run Demo'**<sup>6</sup>

Shortcut: **Ctrl+F5**

Hot Keys: **Alt+R,D**

To setup the way demo messages are created and displayed, see [Set Demo](#)

### Pause

To pause display of the messages, use one of the following commands:


Select **'Run|Pause'**<sup>7</sup>

---

5) This feature is not available in the LogPage/Interceptor Client application

6) This feature is not available in the LogPage/Interceptor Client application

7) This command will only pause the display of new messages but it will not stop LogPage/Interceptor logging the messages. When the application returns to the active mode, you will be able to see all messages that have been logged in the meantime.

Click on the “**Pause**” toolbar button 

Shortcut: **Ctrl+F6**


Hot Keys: **Alt+R,P**

All above pause commands are **toggle commands**. Selecting any of them while in the paused mode, returns the application to the active mode.

## Stop

To stop logging page messages, use one of the following commands:

Select ‘**Run|Stop**’

Click on the “**Stop**” toolbar button 

Shortcut: **F6**

Hot Keys: **Alt+R,S**

When you stop logging page messages in the LogPage/Interceptor Client application, the connection to the server will be disconnected. Every time you start logging page messages, you will have to reconnect using the [authentication process](#).

## Hardware Settings

Hardware settings can be changed only when the LogPage/Interceptor application is stopped. When the application is logging messages all below menu items are disabled.



### Comm Port

Before you [start to log](#) page messages from the Receiver Hardware, you must select a serial port to which your hardware is connected.

Select '**Hardware|Comm Port|<port\_number>**'<sup>8</sup>

Hot Key: **Alt+W,C,<port\_number>**

Only existing serial ports that are registered with the operating system, are displayed on the menu.



- *To review the existing ports, press the "Start" button and go to "Settings|Control Panel|System", select the "Hardware" tab and click on the "Device Manager" button. In the displayed list select the "Ports (COM&LPT)" item.*

Check the port your hardware is using. Your choice is saved automatically.

### Baud Rate

Before you [start to log](#) page messages from the Receiver Hardware, you must select a baud rate that your hardware is using.

Select '**Hardware|Baud Rate|<baud\_rate>**'<sup>9</sup>

Hot Key: **Alt+W,B,<baud\_rate>**

Only two baud rates are available in the current version:

- 9,600
- 57,600

<sup>8</sup>)This feature is not available in the LogPage/Interceptor Client application

<sup>9</sup>)This feature is not available in the LogPage/Interceptor Client application

**Warning:** *You cannot set your hardware baud rate from the LogPage/Interceptor application.*

To change the hardware baud rate:

- LogPage - consult "PDTP Help"
- Interceptor - consult WiPath support

Check the baud rate your hardware is using. Your choice is saved automatically.


### Upload ROM File (Interceptor Only)

The ROM file is used for upgrading your Interceptor unit firmware.

To upload the ROM file

Select '**Hardware|Upload ROM File**<sup>10</sup>'

Hot Key: **Alt+W,U**




Use the "Find" button to select an appropriate file. Only files of the '**rom**' type can be selected.

Warning: Use only files recommended by the WiPath support staff.

Press the "Upload" button to start the uploading process.

You will be warned to reset your unit. That means to turn the unit off and on again. You must start uploading before you hear a beep from the Interceptor unit.

When the uploading starts its progress is displayed in the first field of the [main status bar](#).



### Set Channels Hardware (Interceptor Only)

To set hardware frequency and paging protocol for all four channels

Select '**Hardware|Set Channels Hardware**<sup>11</sup>'

Hot Key: **Alt+W,H**

The frequency and paging protocol for each channel will be set according to the channel current

10) This feature is not available in the LogPage/Interceptor Client application

11) This feature is not available in the LogPage/Interceptor Client application



settings. (see [Set Channel - Changing Channel Setups](#))

Result is displayed in the first field of the [main status bar](#).

## Log Viewer

Log Viewer is a tool that is included as a part of the LogPage/Interceptor application and allows the user to see different log files maintained by the program. Currently LogPage/Interceptor maintains two log files: error log (clients only) and alarm log

The Log Viewer does not allow editing of the log files.

The Log Viewer displays its respective file in real time, which means that when the viewer is opened, any new entry in the file will be added to the display of existing entries.

**Warning:** *While LogPage/Interceptor is running, you will not be able to open any of its log files in another editing tool.*

In its title the viewer shows:

- Application name
- Type of the log file (Alarm Log or Error Log)
- Path and the name of the currently used file

For example, in the screen shot below, you can see that the name of the application is "LogPage Client", the type of the file displayed is "Error Log" and the path of the file is : "C:\Interceptor4\Logs\IPErrorLog1.txt".



To clear the log display, select the "Clear" button (or the "Clear" menu item on the popup menu).

Shortcut: **Ctrl+Del**

It will clear the display but will not delete the log file.

To close the viewer, press the "Close" button, or the "**Esc**" key.

For more available commands right-click on the display and select the appropriate command from the popup menu.



To move to the beginning of the file select "Go To Start" (**Ctrl+Home**) and to move to the end select "Go To End" (**Ctrl+End**).

If you want the log display to stay always on the top of all other forms in the program, select "Stay On Top". If this option is selected, the menu item will have a check mark displayed.

To change the background colour of the viewer select "Settings|Colour" (**Ctrl+B**) and to set the font select "Settings|Font" (**Ctrl+F**).

You can also select any part of the text and copy it to the clipboard.

All changes to the log viewer settings are stored automatically.

## Open Alarm Log Viewer

Alarm Log Viewer displays a file that is used to log watchdog alarm messages, if the user selects this option in the "[System - Alarm Log](#)" dialog.

Select **File | Show Alarm Log'**

Shortcut: **Shift+Ctrl+A**

Hot Keys: **Alt+F,S**

All above commands will open the "Alarm Log Viewer".

## Open Error Log Viewer

Error Log Viewer<sup>12</sup> displays a file that logs the client application connection errors. It is available only in the [client](#) type of application.

Select **File | Show Error Log'**

Shortcut: **Shift+Ctrl+E**

Hot Keys: **Alt+F,E**

All above commands will open the "Error Log Viewer".

<sup>12</sup>) Available only in the client type of the LogPage/Interceptor application.

# System Settings

## Set System

Used to set values and functionalities that are used by the whole application.

Select **'Settings|Set System'**

Shortcut: **Ctrl+S**

Hot Keys: **Alt+S,S**

Currently, the system has following settings:

- [Default Colours](#)
- [Messages](#)
- [Message Display](#)
- [i-Page Server](#)
- [Email](#)
- [Paging](#)
- [SMS](#)
- [Alarm Log](#)
- [Tcp Server](#)
- [Tcp Client](#)

## Save System Settings

Neither of changes you make to any of the pages are saved automatically. Saving changes works separately for each page.

E.g. If you have entered some changes, on the “Messages” page, the “Save” button will become enabled but only when are you on that page. If you move to another page it will resume value for that page. Your changes on another page will not be lost, so you can always go back and save or cancel changes.

If you wish to save some changes, go to the respective page and save them by clicking the **“Save”** button or the **“Enter”** key.

Shortcuts: **Ctrl+S or Enter**

**Warning:** *If you close the dialog box without saving changes on any of the pages, you will get a warning and another opportunity to save your changes. If you choose 'Yes' to save changes on exit, all changes on all tabs will be saved.*

## Cancel Changes

If you do not wish to save your changes to any of the settings and wish to return to previous settings, you can cancel<sup>1</sup> all the changes for that tab by selecting the **“Cancel”** button.

---


1) You can cancel only unsaved changes.

The cancel button works the same way as the “Save” button i.e. its functionality is always associated only with the currently opened tab.

Shortcut: **Ctrl+Q**

## Set Default Colours

Used to set default background and font colours for each of the three types of filter.



The user is able to set different display colours for every particular filter created (see Set Filter – Filter Colours), however if no customised colours are set then the system will use the default colours for that filter type.

These colours are also used when displaying report results


Click on the “Fill” button for the appropriate filter type and select default background colour for that filter type.

Click on the “Font” button for the appropriate filter type and select default font colour for that filter type.

The new selection will display in the text box above the selection buttons.

## Set Messages

Settings used by LogPage/Interceptor messaging system for manipulation, storage and display of messages.



## Display Number

To set the maximum number of messages that will be displayed in the message grid, enter an appropriate value into the "Displayed Msgs No" box. Maximum number is 10,000 and minimum is 10. Only the newest messages will be displayed.

When the program starts it will attempt to load the maximum number of messages from the database into the display. If the database contains more messages, the newest messages (up to the maximum number) will be loaded. If there are less messages in the database, all of them will be loaded.

## Message Buffers

Message buffers, are used to prevent the loss of messages due to processing delays or to control memory used by the messaging system.

The application stores all messages received in buffers before processing them.

If you suspect that some messages may be lost due to slow processing, increasing the buffers size

may help. On the other hand, if the computer is low on memory, decreasing the buffer size will lower memory consumption.

In reality, it is not very likely that you will ever need to change these values. Most contemporary computers can process messages much faster than they could be delivered by the serial ports and the buffers are just additional security.

Maximum number for both buffers is 10,000 and minimum is 100.

### **Delete Old Messages**

Old messages may be deleted manually or the program can be set to delete them automatically.

The “Last Time Deleted” control shows the last time old messages were deleted.


In the “Delete Interval” control enter the number of days that the program will keep messages in the database. All messages older than that interval will be deleted.

If you select the “Auto Delete” control, every time the program starts it will delete all messages older than the delete interval. If the program runs continuously, every day between midnight and 2:00 AM it will check for old messages and delete them.

If you select the “Manual Delete” control, all messages older than the delete interval will be deleted when the “Delete” button is clicked.

## Set Message Display

Settings used by the LogPage/Interceptor main display system for displaying full message view on the main form in the active and paused mode.



To set a background colour of the message view, select one of the colours from the "Fill Colour" control.

To set a font colour of the message view, select one of the colours from the "Font Colour" control.

If the message has been processed by a filter, it could have some of the words selected. To set a font colour of the selected words, choose one of the colours in the "Selection Colour" control. If you want selected words to appear bold, make sure that the "Display Bold" control is checked.

To select a font type that will be displayed in the full message view control, select the font name in the "Font Type" control. You can use any font type installed on the machine.


To select the font size, select a value in the "Font Size" control.

All your settings will be immediately displayed in the "Demo" control.



## Set i-Page Server

LogPage/Interceptor uses its own paging server (i-Page Server) to send page and SMS messages required by the program. The software can connect to the local instance of the i-Page server or to any other i-Page server running on any machine accessible through the Internet or your LAN.



## Selecting i-Page Server

Before you select a new option for i-Page Server, you must stop the server currently running.

If the server is running the "Stop" button will be enabled. Select the "Stop" button and wait for the message that will tell you that you are not connected to the currently selected server. The "Stop" button will change into the "Start" button.

Select the server in the "Select i-Page Server" group of controls.

Save your changes before you attempt to start the server. See Save System Settings

Select the "Start" button and wait for the message that advises that LogPage/Interceptor is connected to your selected i-Page Server.


**Warning:** *If neither paging nor SMS is enabled, you will get a warning message and an option to connect to the selected i-Page Server anyway.*

## Local i-Page Server

To connect to the i-Page Server running on your machine, select the "Local" option.

To run the server locally, you will need either a modem installed, and your computer must be connected to the active telephone line, or you must have an internet connection for IP enabled carriers, or you must be connected to a SitePage on-site paging system via a serial port or LAN.

You must also have i-Page Server software installed and running. LogPage/Interceptor installation will install and register the i-Page Server for you. It will also automatically run this software and connect to it on start up, but only if [paging](#) and/or [SMS](#) is enabled.

If it is running you will see a pager icon in the computer task bar tray (bottom-right corner of the desktop). 

## Remote i-Page Server

To connect to an i-Page Server running on another machine, select the "Remote" option.

To run the server remotely, you must be able to connect to that machine through your network or the Internet.

You need also to enter the destination machine IP address into the "Server IP Address" control and the paging server port number into the "Server IP Port" control (default 215).

LogPage/Interceptor installation will connect to the remote server automatically on the start up, but only if [paging](#) and/or [SMS](#) is enabled.

## Set Email

LogPage/Interceptor uses its own email client to send email messages generated by filters, alarms and reports. This page is used to enter settings for the application email client.

To use the email functionality, you must be connected to the Internet.

To enable email functionality for the whole application, tick the “Email Enabled” check box. If you do not check this box, all email functionality in the program will be disabled.

The screenshot shows the 'LogPage - Edit System - Email' window. On the left is a tree view with the following items: Default Colours, Messages, Message Display, i-Page Server, Email (selected), Paging, Mobile, Alarm Log, and i-Page Log. The main area contains the following settings:

- ☒ Email Enabled
- SMTP Settings**
  - Host: mail.yourserver.com
  - Port: 25
  - Timeout: 0
  - Retries: 1
- Sender Email Address: joe@server.co.nz
- ☒ Use Password
  - Login Name: joe+server.com
  - Password: [masked]
- Email Client Settings**
  - Message Length: 0
  - Buffer Size: 1,000
  - Delay: 500

On the right side of the window are buttons: Help, Send, Delete, Cancel, Save, and Close.

## SMTP Settings

This is a close-up of the SMTP Settings section. It includes the following fields:

- Host: smtp.gmail.com
- Port: 465
- Timeout: 0
- Retries: 1

## Host

Enter IP address of your SMTP server into the “Host” control. This is the server that your network is using for sending emails.

## Port

Enter the port number that your server is using into the “Port” control. Although some servers can handle secure emails through the usual SMTP port **25**, most of them will use either port **465** or **587** for that.

## Timeout

Enter an interval that the client will wait before it timeouts sending of the email message. The value is expressed in seconds.


Recommended value for email: **0** seconds. In that case LogPage uses a value defined by the TCP/IP stack implemented on the machine.

## Retries

If the client does not succeed in sending the message, it can repeat the procedure certain number of times. Enter the number of retries in the “Retries” box. Maximum number is 7 and minimum is 1.

Recommended value for email: **1**. Higher values can cause problems with your SMTP server.

## Sender Email Address

A screenshot of a web form control labeled "Sender Email Address:". Below the label is a text input field containing the text "userName@gmail.com". The entire control is enclosed in a light gray border.

Enter the sender’s email address into the “Sender Address” control.

This address will be used as a sender’s address in all email messages sent by LogPage.

When you are using a secure connection, most SMTP servers expect an address that they know about, otherwise they usually discard a message as a spam. The safest thing is to enter an email address that is registered on the SMTP server (e.g. your email address). Some servers allow you to add to your profile other emails (e.g. “Recovery email”). You can also use those email addresses here, because the server know about them.

## SSL/TLS Setting

SSL/TLS Settings

Authentication:  
 Encrypted Password ▼

User Name: krivop1@gmail.com Password: xxxxxxxx

Connection Security: TLS Start SSL/TLS: On connection ▼

## Authentication

None  
 Normal Password  
 Encrypted Password

Select the type of authentication from the "Authentication" control. You can select one of the following options:

- |                           |  |
|---------------------------|--|
| <b>None</b>               | Select this option when no authentication is required by the SMTP server.  |
| <b>Normal Password</b>    | Select this option when the SMTP server requires authentication, but authentication data are sent in a plain text.   |
| <b>Encrypted Password</b> | <p>Select this option when the SMTP server requires authentication, but authentication data are sent in a secure manner to the server.</p> <p>The SMTP server must support some of <b>SASL</b> mechanisms for a secure authentication.</p> |

**Note:** *SASL stands for "Simple Authentication and Security Layer". It is a an IETF standard based on [RFC 4422](#). It defines a framework for authentication and data security in Internet protocols.*

*The framework is implemented through different SASL mechanisms. Each of those mechanisms defines a level of encryption and series of challenges and responses that are exchanged between the SMTP server and a client during the authentication. SASL mechanisms are registered with IANA. In this special version, LogPage implements only a small subset of SASL mechanisms. Version 4 implements much larger number.*

It is not unusual for secure SMTP servers to use "Normal" password and send it in a plain text.

- Enter your account user name in the "User Name" control.

- Enter your account password into the "Password" control.

## Connection Security



Select the type of connection security from the "Connection Security" control. You can select one of the following options:

- |             |  |
|-------------|--|
| <b>None</b> | The whole communication between the i-Page and SMTP server, including an email message, is carried out in a plain text.  |
| <b>SSL</b>  | The whole communication or a part of it (depends on the settings in " <a href="#">Start SSL/TLS</a> ") is encrypted according to the SSL (Secure Socket Layer) specifications.<br>LogPage implements versions SSL 2.0 and SSL 3.0, which is defined in IETF historic document <a href="#">RFC 6101</a> . |
| <b>TLS</b>  | The whole communication or a part of it (depends on the settings in " <a href="#">Start SSL/TLS</a> ") is encrypted according to the TLS (Transport Layer Security) specifications.<br>i-Page Server implements versions TLS 1.0, which is defined as IETF standard <a href="#">RFC 5246</a> .           |
| <b>Auto</b> | The whole communication or a part of it (depends on the settings in " <a href="#">Start SSL/TLS</a> ") is encrypted according to the SSL or TLS specifications.<br>i-Page Server negotiates with the SMTP server which cryptographic protocol they are going to use during their communication.          |

## Start SSL/TLS

To set whether the connection will be encrypted immediately or on a client request, select from the "Start SSL/TLS" control one of the following options:

1. On connection - the connection is encrypted from the start
2. On request – the connection starts as unencrypted and during the connection LogPage requests from the SMTP server to switch to TLS or SSL

Both of above options can be used and they depend on SMTP server settings. Most likely case is that the server will require the "On Connection" option on its port 465 and "On Request" on its port 587.

# Example

Here is a working example on how to relay your email messages through the Google Web based Gmail SMTP server.

To use Gmail SMTP server you need to open a Gmail account. This is just a normal email account, and it is free.

Let us assume that your Gmail email address is :

[nicole@gmail.com](mailto:nicole@gmail.com)

Enter the following settings on the LogPage “Email” dialog:


Host	<a href="mailto:smtp.gmail.com">smtp.gmail.com</a>
Port	<b>465</b>
Sender Address	<a href="mailto:nicole@gmail.com">nicole@gmail.com</a> ( <i>your account's email address</i> )
Authentication	<b>Encrypted Password</b>
User Name	<a href="mailto:nicole@gmail.com">nicole@gmail.com</a> ( <i>your account's full email address</i> )
Password	<b>Your account's password on Gmail</b>
Connection Security	<b>TLS</b>
Start SSL/TLS	<b>On connection</b>

## Testing Email Settings

To test your email settings, click on the “Send” button.

**Warning:** *All your settings must be saved before you test them.*

The “Test Email Settings” dialog box will pop up.



Enter the email address of the receiver into the “Send To” control. If you enter an address that is not a properly formatted email address, your message will not be sent and you will get an error message.

You can also test file attachment functionality (used by the reporting tool). You can attach files of any type to your test email.

To do so click on the “Add” button and select a file. If you wish to delete files already attached, select the file name in the “Attach Files” box and click on the “Delete” button.

Press the “Send” button or the Enter key to send the test email.


The system will advise whether the email has been sent successfully. If the system fails to send the message it will display an error message with an indication of the reason for the failure. In such a case you should correct your settings and try again.

- ☒ *You may need to wait several seconds before you get any response message to your test. It partially depends on values that you have set in the “Timeout” and “Tries” controls, but also on other factors that are outside of control of this application.*
- ☒ *If you receive a success message that does not mean that your email is sent all the way to the receiver’s mail box. It means that your SMTP server has accepted your email message and will try to send it to the designated address.*



## Set Paging

LogPage/Interceptor uses its own paging server (i-Page Server) to send page messages required by the program. This page is used to enter settings that this server requires to connect to your paging service provider. Most of these settings are determined by your paging service provider. You may have to contact your paging service provider to obtain these settings



To use this functionality, you need modem installed and your computer must be connected to the active telephone line.

You must also have “i-Page Server” software installed and running. LogPage/Interceptor installation will install and register that software for you. It will also automatically run this software and connect to it on start up, but only if paging and/or [SMS](#) is enabled.

To enable paging functionality for the whole application, check the “Paging Enabled” box. If you do not check this box, all paging functionality in the program will be disabled.

**Warning:** *If neither paging nor [SMS](#) is enabled, “i-Page Server” will not be loaded. After you check the “Paging Enabled” box, select the “Save” button and go to the “[Set i-Page Server](#)” page to start the server.*

## Carrier Settings

Select networking protocol from the “Carrier Type” control. This is the protocol that you are going

to use to connect to your paging service provider

Enter the phone number of your paging service provider into the “Phone No” control. The “Phone No” control is displayed only if you select “TAP Modem” or “PACNET” for the carrier type.

Select a modem baud rate from the “Modem Baud Rate” control.

Select modem settings from the “Data Settings” control. The format is “data bits – parity – stop bits”.

Select maximum message length from the “Message Length” control.

If your paging service provider requires authentication, check the “Use Password” check box and enter your password into the “Password” control. LogPage/Interceptor will store that information in a secure way.

### Common Settings

Protocol	Baud Rate	Data Settings	Message Length
TAP Modem	1200	7,E,1	160
PACNET	9600	7,O,1	120
TAP Direct	9600	8,N,1	200

If you have selected “PACNET” as your carrier type, enter values into the “NUI” and “NUA” controls.

**NUI:** NHVCRS7JQD3F (NZ PACNET only)


**NUA:** 43100000005 (NZ PACNET only)

### Testing Pager Settings

To test your page settings, click on the “Send” button.

**Warning:** *All your settings must be saved before you test them.*

In the dialog box that appears, enter a valid pager number into the “Enter Pager Number” control. The program will remember that number for the next test.




Press the “OK” button or the Enter key to send the test page.

You will always get a message about the success or otherwise of your test from the system. If it is an error message, it will give you details about the error that occurred. In this case correct your settings and try again.

- ☒ *You may need to wait several seconds before you get any response message to your test. It depends on factors that are outside of control of this application.*
- ☒ *If you receive a success message it means that the i-Page Server has accepted your page message as valid (with correct settings) and will try to send it to the designated pager. Whether it will succeed, depends on many factors outside control of this application (among others, whether the pager number is still valid).*

## Set SMS

LogPage/Interceptor uses its own server (i-Page Server) to send text messages to a mobile phone. This page is used to enter settings that this server requires to connect to your mobile service provider. Most of these settings are determined by your provider. You may have to contact your mobile service provider to obtain these settings



To use this functionality, you need a GSM/GPRS module with a SIM card, connected to the computer serial port (COMM). You can also use your mobile phone if you can connect it to the serial port.

You must also have “i-Page Server” software installed and running. LogPage/Interceptor installation will install and register that software for you. It will also automatically run this software and connect to it on start up, but only if [paging](#) and/or SMS is enabled.

To enable SMS functionality for the whole application, check the “SMS Enabled” box. If you do not check this box, all SMS functionality in the program will be disabled.

**Warning:** *If neither [paging](#) nor SMS is enabled, “i-Page Server” will not be loaded. After you check the “SMS Enabled” box, select the “Save” button and go to the “[Set i-Page Server](#)” page to start the server.*

## Settings

If the SIM card in your module (or mobile phone) does not have embedded number of your provider's SMS centre, or you want to use another SMS centre, check the "Use Number" control and enter the SMS centre number into the "SMS Centre No" control.

If the SIM card in your module (or mobile phone) uses a PIN number, check the "Use Pin" control and enter the PIN number into the "SIM Pin No" control.

If you are using Unicode characters in your text messages, check the "Use Unicode" control.

## Other Settings


The rest of settings (Modem baud rate, Data settings and Message length) can be found in your GSM/GPRS module or mobile phone manual.

## Testing SMS Settings

To test your SMS settings and send a text message to a mobile phone, click on the "Send" button.

**Warning:** *All your settings must be saved before you test them.*

In the dialog box that appears, enter a valid mobile phone number into the "Enter mobile phone number" control. The program will remember that number for the next test.




Press the "OK" button or the Enter key to send the test message.

You will always get a message about the success or otherwise of your test from the system. If it is an error message, it will give you details about the error that occurred. In this case correct your settings and try again.

- ☒ *You may need to wait several seconds before you get any response message to your test. It depends on factors that are outside of control of this application.*
- ☒ *If you receive a success message it means that the i-Page Server has accepted your SMS message as valid (with correct settings) and will try to send it to the designated mobile phone. Whether it will succeed, depends on many factors outside control of this application (among others, whether the mobile phone number is still valid).*

## Set Alarm Log

LogPage/Interceptor will log all watchdog alarm messages to the alarm log file.



### Alarm Log Settings

To enable the logging of alarm messages check the "Enable Alarm Log" check box.

To set a number of messages that will be logged in one file enter a value into the "Items per File" control.

To set a number of files that the application will create before starting to overwrite the first one, enter a value into the "No of Files" control.

The user can also set the format of the message that will be logged to the file. see "[Set Alert Message](#)"

The system will insert a log message number and a date in front of the user's custom message format.

Final log item format:

Alarm No: <log\_item\_number>  
<date\_time>  
<user\_custom\_message>

To test your message format select the "Show" button on the right-hand side.

## Log Display Settings


LogPage/Interceptor includes a log viewer - tool that allows the user to see all the entries in the log file in real time.

To set the a background colour of the viewer, select the "Colour" button (shortcut **Ctrl+C**).

To set a font of the viewer select the "Font" button (shortcut **Ctrl+F**).

## Set TCP Server

This page is available only in LogPage/Interceptor [Server](#) application.



### Host

“Host” is a read-only control. It shows current IP address of the server or its name. It can be used as a quick reference when setting a client. If you enter this value into the same control in the LogPage/Interceptor Client application, you will be able to connect to this server.

### Port

Enter a TCP port number into the “Port” control. This is the TCP port that LogPage/Interceptor Server uses to connect to the client.

Port numbers can range from 0 to 65,535. Be aware that ports in range from 0 to 1,023 are reserved ports and if you use them be sure that they are not conflicting with another application that runs on the same machine as LogPage/Interceptor Server.

You may also need to change settings of the firewall that runs on the server machine. Before selecting a server port we recommend you consult your network administrator.



## Client Buffer Size

LogPage/Interceptor Server has additional memory buffers to store messages intended for the client, while waiting on TCP connection to come through. Client buffers are used to prevent the loss of messages due to lower speed or congestion of the network or to control memory used by the messaging system.

If you suspect that some messages may be lost due to slow network traffic, increasing the buffers size may help. On the other hand, if the computer is low on memory, decreasing the buffer size will lower memory consumption.

Maximum number for the client buffer is 10,000 and minimum is 100.

## Keep Alive Timeout

Enter a value in seconds into the “Keep Alive Timeout” control.

Due to the nature of TCP/IP connection, LogPage/Interceptor Server is not able to tell if one of its clients has lost its connection until it tries to send a message to it. If there are not many messages on the client’s channel it may take some time for the server to discover that. The result could be lot of dead connections maintained by the server.

To prevent this occurring the server uses a ‘Keep alive’ function. This means that the server sends a short message every ‘Keep Alive Timeout’ interval to all of its clients. If a connection is broken, the server will assume that the client has disconnected and stop logging messages into that client buffer, remove all messages from the buffer and clear the buffer.


The server will not log the client out of the system. That will allow the client to reconnect without passing through the authentication procedure.

This method is also used by the client to assess its connection to the server and make a decision on starting the reconnection procedure.

(see [Reconnect Timeout](#))

## Set TCP Client

This page is available only in LogPage/Interceptor [Client](#) application.



### Host

Enter the IP address of the computer that LogPage/Interceptor Server is running on into the “Host” control. The best thing is to enter the same value that is shown in the same control on the server.

### Port

Enter the server port number into the “Port” control. This value must be the same as the value that is already entered in the same control on the server.

### Reconnect Timeout

Enter a value in **seconds** into the “Reconnect Timeout” control.

As soon as the client connects to the LogPage/Interceptor Server it starts the timer that runs for the “Reconnect Timeout” number of seconds. If during that period the client does not receive any message from the server, it assumes that the connection is broken and starts the reconnect procedure. Any message from the server resets the timer.

In periods when there are not many paging messages, the client uses the ‘[keep alive](#)’ message from

the server to put off the reconnect procedure. For that reason it is important that the “Keep Alive Timeout” interval has always a smaller value than the “Reconnect Timeout” value. How big the difference between those two values should be, depends on the speed and state of the network.

**Warning:** *Keep in mind that the reconnect procedure is not simple and uses a lot of computer resources and memory. Additionally creating another connection to the server from the same client may have unpredictable consequences.*

## Connection Error Log

To help the user to troubleshoot connection problems, LogPage/Interceptor Client application maintains a connection [error log](#) file.

In the “Connection Error Log” group of controls you can set a number of items that will be stored in one file by entering its value into the “Items per File” control. You can also set a number of files that the application will create before starting to overwrite the first one, by entering respective value into the “No of Files” control.

## User Accounts


User accounts can be created and edited only by the system administrator and users that have “Edit Users” rights assigned by the administrator. Other users have some limited rights to edit their own account. see [Edit Personal Account](#)

This functionality is not available in the LogPage/Interceptor [Client](#) application. If you wish to set users’ accounts that will be used by the client, you have to do it in the LogPage/Interceptor [Server](#) application.

Select ‘**Settings|Set User**’

Shortcut: **Ctrl+U**

Hot Keys: **Alt+S,U**



## New User

Click on the “New” button on the ‘Edit User’ dialog box.

Shortcut: **Ctrl+N**

Enter a user’s account name in the “User Name” control.

The user will use that name as a ‘user name’ to log into LogPage/Interceptor. The system will also

create a first-time-login password identical to the user name.

**Warning:** *User name cannot be changed after you save the user.*

## Edit User

Enter a properly formatted email address into the “Email” control (optional).

Enter a pager number into the “Pager No” control (optional).

Set user’s permissions in the “Permissions<sup>1</sup>” control, by checking a check box next to the permission you wish to assign to the user.

## Change User's Password

To change the user’s password, click on the “Set Password” button.

Shortcut: **Ctrl+P**



Enter a new password into the “New Password” control.

Enter the new password again into the “Confirm New Password” control.

Click the “OK” button or press the Enter key.

## Save User

Changes made to the user settings are not saved automatically. If you have changed any settings, the “Save” button will become enabled. If you wish them to take effect in the program, you must save them by clicking the “**Save**” button or the “**Enter**” key.

Shortcuts: **Ctrl+S or Enter**

**Warning:**

- *If you select another user without saving changes, your modifications will be lost.*
- *If you close the dialog box without saving changes, you will get a warning and another opportunity to save your changes.*

---

1) If the selected user is “Admin” the “Permissions” control is disabled, because the admin account has all permissions assigned to it and it cannot be changed.

## Delete User

To delete<sup>2</sup> selected user, select the **“Delete”** button.

Shortcut: **Ctrl+Del**

You will get a warning from the system that the user will be deleted permanently and the option to delete it or not. If you choose to delete it anyway, the user will be deleted permanently.

## Cancel Changes

If you are not satisfied with changes to the user and wish to return to all previous settings, you can cancel<sup>3</sup> all the changes at once by selecting the **“Cancel”** button.

Shortcut: **Ctrl+Q**


---

2) It is not possible to delete the “Admin” account and it is not possible to delete the user that is currently logged in.  
This means that you cannot delete yourself.

3) You can cancel only unsaved changes.

## Permissions

The user does not have automatic access to all LogPage functionalities. The administrator can select which feature is available to which account. To do that, she must set a permission for every functionality that is exposed by LogPage. This is done by checking a check box for an appropriate permission.



Permissions:

- ☐ Setup System
- ☐ Edit Users
- ☐ Edit Channels
- ☐ Edit Filters
- ☐ Delete Messages
- ☐ Hardware Setup
- ☐ Create Reports
- ☐ Set Grid
- ☐ Set Demo
- ☐ Run Demo
- ☐ Export Filters
- ☐ Import Filters

Permission	Explanation
Set System	The account is allowed to change system settings
Edit Users	The account is allowed to create, edit and delete other accounts
<a href="#">Edit Channel</a>	The account is allowed to create, set and delete a channel – Interceptor only
Edit Filters	The account is allowed to create, edit and delete message filters
Delete Messages	The account is allowed to delete all or selected old messages
<a href="#">Hardware Setup</a>	The account is allowed to set the channel protocol and frequency - Interceptor only
Create Reports	The account is allowed to create, edit, delete and run reports
Set Grid	The account is allowed to change settings to the main display grid
Set Demo	The account is allowed to change settings for demo messages
Run Demo	The account is allowed to run LogPage in its demo mode
Export Filters	The account is allowed to export filters into a special filters file
Import Filters	The account is allowed to import filters from a special filters file

## Edit Personal Account

Every user can change<sup>4</sup> some of their account settings.

To change your own account settings, select **'File|Set Your Account'**.

Shortcut: **Ctrl+A**

Hot Keys: **Alt+F,A**

In the current version you are only allowed to change your email address and pager number.

You have to save your changes. see "[Save User](#)".

## Change Personal Password

Select **'File|Change Password'**.

Shortcut: **Ctrl+P**

Hot Keys: **Alt+F,P**.



Enter your old password into the "Old Password" control.

Enter a new password into the "New Password" control.

Enter the new password again into the "Confirm New Password" control.

Click the **"Save"** button or press the **"Enter"** key.

If the change to the password was successful, you will get the message from the system. Otherwise, you will get an error message that explains in detail what went wrong.

---

4) This feature is not available in the LogPage/Interceptor [Client](#) application.

5) This feature is also available in the LogPage/Interceptor [Client](#) application, but you might wait for several seconds to receive either a success or error message from the server.



# Filters


## Set Filter

LogPage/Interceptor has an extensive inbuilt filtering capability. Every message can be filtered against range of criteria and a large number of filters can be setup.

Select '**Settings|Set Filter**' or click on the "**Set Filter**" toolbar button 

Shortcut: **Ctrl+F**

Hot Keys: **Alt+S,F**



## Edit Filter Dialog Layout

The "Edit Filter" dialog consists of three panels. The left panel is a tree-like list of all filter settings

available. The middle panel shows values for the selected setting. The right panel contains editing command buttons.

Selected Node (left panel)	Feature (middle panel)
<b>Filters</b>	Displays all existing filters and some of their setting values in the grid
<b>Selected Filter</b>	Criteria for the selected filter
<b>Colours</b>	Background and font colours for the selected filter
<b>Sound</b>	Alert sound for the selected filter
<b>Paging</b>	Paging messages settings for the selected filter
<b>Email</b>	Email messages settings for the selected filter
<b>Mobile</b>	SMS message settings for the selected filter
<b>Traffic Monitor</b>	Settings for monitoring selected filter occurrences
<b>Edit Message</b>	Tools for modifying message content for the selected filter
<b>Popup Alert</b>	Popup alert form settings for the selected filter
<b>Channels</b>	Channels that the selected filter is valid for
<b>Filter Summary</b>	Displays summary of the selected filter settings
<b>Set Grid</b>	Customizing grid that displays all existing filters

## New Filter

Click on the “New” button in the ‘Edit Filter’ dialog box.

Shortcut: **Ctrl+N**


The “Selected Filter” node becomes selected and the middle panel shows criteria for the new filter.

Enter a filter name in the “Filter Name” box.

Select a filter type in the “Filter Type” control.

## New Filter From Message

Right-click on the message row on the [main form](#) and from the popup menu select the "New Capcode Filter" option.



Shortcut: **Shift+Ctrl+F**

The system will create a new capcode filter and copy the selected message capcode into the filtering criteria.

## **Edit Filter**


### ***Selecting Filter for Editing***

Click on the “Filters” node in the left panel to get the grid with all existing filters displayed. Select the filter you wish to edit in the grid.

### ***Selected Filter***

Select the “Selected Filter” node to get the panel with filtering criteria settings.





To change the filter name<sup>1</sup>, enter a new name into the “Filter Name” control.

To change the filter type, select a type in the "Filter Type" control.

**Warning:** *If you change the filter type for the existing filter, you will loose all its previous values on the "Selected Filter" page.*

To enable the filter check the “Enabled” check box. If this control is not checked, the program will disregard the filter when filtering messages but the filter will still exist.

Depending on the filtering type selected, you will get different type of filtering controls.


- [Capcode Filter Type](#)
- [Text Filter Type](#)
- [Both](#)

## Filter Colours

Every filter can be assigned a different background and font colour.

Select the “Colours” node to get the panel with the selected filter colour settings.

<sup>1</sup>) You can assign the same name to different filters.



Click on the “Fill” button and select a background colour for that filter.


Click on the “Font” button and select a font colour for that filter.

You can see how these colours match in the text box above the buttons.

### **Sound Alert**

When the program finds a message that matches filtering criteria, it can sound an alert to warn the user. Every filter can be assigned its own sound alert.

Select the “Sound” node to get the panel with the selected filter sound settings.



To set a sound alert for the filter, enter a path to a desired “Wave” file into the “Sound Alert File” control or press the “Find” button to use a usual Windows file search facility.

After you select a file the application will check its format. If the file format is incompatible, you will get an error message and the program will not allow you to use that file.

When the file is assigned to the filter, the length of the sound it contains will be displayed in the “Sound File Length” control. It is not a very good idea to use lengthy sounds for the filter alerts. You can also play the file by clicking the “Play” button.

To enable the sound alert when the message matches the filtering criteria, you must enable the “Sound Enabled” control.

### ***Send Pager Message***

When a message matches the filtering criteria (filter hit) a message can be sent to designated pager numbers. The message can be also sent when the filter hit occurs a certain number of times in a certain time interval (traffic monitor hit).

To set page messages for the selected filter, select the “Paging” node. see “[Alerts – Pager Message](#)”

### ***Send Email Message***

When the program finds a message that matches the filtering criteria (filter hit), it can send an email message to the designated email addresses. The message can be also sent when the filter hit occurs a certain number of times in a certain time interval (traffic monitor hit).

To set email messages for the selected filter, select the “Email” node. see “[Alerts – Email Message](#)”

### ***Send SMS Message***

When a message matches the filtering criteria (filter hit), an SMS message may be sent to designated mobile phone numbers. The message can be also sent when the filter hit occurs a certain number of times in a certain time interval (traffic monitor hit).

To set SMS messages for the selected filter, select the “Mobile” node. see “[Alerts – SMS Message](#)”



## Filter Traffic Monitor

The number of times a filter hit occurs in a predefined period may be monitored<sup>2</sup> and alerts may be generated if the number of filter hits meets or exceeds the specified number within the defined time interval.

To set the number<sup>3</sup> of filter hits you are testing for, enter a value into the "No Of Filter Hits" box.

To set the time interval<sup>4</sup> during which this number of hits would generate an alert, enter values into the "Traffic Monitor Interval" boxes.

To enable the filter traffic monitor functionality check the "Enabled" box.

The filter traffic monitor functionality can send an unlimited number of paged, SMS or email messages when the filter hit occurs the indicated number of times within the defined interval. You must enable each of the required alert type that you wish to generate, in the "Enable Filter Traffic

2) The occurrence test is not designed to be a statistical but an alert tool. That means that it cannot be set to follow filter hits over a long period of time

3) The maximum number of filter hits that can be set is 1,000

4) The maximum time interval is 720 hours (1 month).

Monitor Alerts" group of boxes ( "Paging Enabled", "Sms Enabled" or "Email Enabled"). You must also select the recipients' email addresses, pager or mobile numbers on their respective pages and check the "Traffic Monitor Hit" control for each of those addressees to whom you wish to send the Filter Traffic Monitor alert. see [Send Pager Message](#), [Send Email Message](#) and [Send SMS Message](#)


The Filter Traffic Monitor functionality can also generate a popup message on screen. To enable this, check the "Popup Enabled" box in the "Enable Filter Traffic Monitor Alerts" group of boxes. You must also check the "Traffic Monitor Hit" box on the [filter popup alert](#) dialog.

To use the same message format in all enabled alerts, check the "Use For All Traffic Monitor Alerts" box. This will override any individually assigned message formats defined in the [Paging](#), [Mobile](#) and [Email](#) dialogues. If left unchecked the Filter Traffic Monitor alert generated for each applicable user will use the format defined in the individual dialogues.

To define a message format common to all alerts, edit the message as described in “[Set Alert Message](#)”

## Edit Message

The "Edit Message" dialogue enables the user to change internal content of the received page message before resending it using the filter criteria. It is especially convenient tool for manipulating message content when the message has a standardised, predefined content and/or format. The edited message can be then used as a part of the email, page or SMS message or as a part of the popup alert display.



The "Separate Message Into Segments" group of controls can be used to separate (parse) the received message into different segments and then combine those segments into a new message.

To set a message segments delimiter, select a value in the "Separate Message At" group of controls. The most common delimiters are spaces and commas, however other characters may be used by selecting the "Other" option and entering any printable ASCII character in the available edit box. The original message will be separated into different segments whenever the delimiter is encountered in the message.

To create a new message from the segments created, enter each segment number that you wish to include in the new message into the "Use Message Segments" control. The Segments are numbered '1, 2 ...'. The separate segment numbers may be separated in the control with any of the following characters:

<b>space</b>	<b>1 3 7</b>
<b>comma</b>	<b>1,3,7</b>
<b>colon</b>	<b>1:3:7</b>
<b>semicolon</b>	<b>1;3;7</b>
<b>dash</b>	<b>1-3-7</b>
<b>any combination of above</b>	<b>1 3,5-7</b>

The segments may be connected in the new message with any ASCII characters or string by entering those characters into the "Join Segments With" control.

For Example:

Original message	<b>This Is A Test Message For You</b>
Separate message at	<b>spaces</b>
Use message parts	<b>2,1,6,7</b>
Join parts with	<b>' '</b>
New message	<b>Is This For You</b>

To modify the message by replacing or deleting characters or strings, use the "Modify Message"<sup>5</sup> controls.

Enter the character(s) or string that you wish to replace into the "Replace" box. Enter the replacement character(s) or string into the "Replace with" box.

If you wish to delete character(s) or a string, enter it into the "Replace" box, and leave the "Replace with" box blank.

To ensure the criteria is case sensitive, check the "Case Sensitive" box.

If you wish to delete a specific number of characters from the beginning or the end of the message, use the "Delete Characters"<sup>6</sup> group of controls.

In the "Delete From Message" control select from the options:

- |                |  |
|----------------|--|
| First          | - to delete characters from the beginning of the message             |
| Last           | - to delete characters from the end of the message                   |
| First and Last | - to delete characters from the beginning and the end of the message |

Enter the number of characters you wish to delete into the "No of Characters" control.

To use the edited message as a part of the email, page or SMS message or as a part of the popup display message, select the "Edited Message" option from the "Variable Fields" combo or from the popup menu. See [“Set Alert Message”](#)

---

5) The "Modify message" functions are applied after the "Separate message into Segments" function (if enabled)

6) The "Delete Characters" function will use the result of the "Separate message into Segments" function (if enabled) and the result of the "Modify message" functions (if enabled.)


## Popup Alert

When the program finds a message that matches filtering criteria, it can popup a form to alert the user. Each filter can be assigned its own popup alert, with basic information about the message and the filter.

To set a popup alert for the filter, click on the “Popup Alert” node. see [Set Popup Alert](#)

## Set Channels

Select the “Channels” node to get the panel with the selected filter channel<sup>7</sup> settings.



Select the channels that the filter is enabled for.

## Filter Summary

Displays summary of all settings for the selected filter.

Shortcut: **Ctrl+I** or double-click on the filter in the grid.

see [View Filter Info](#)

---

7) In LogPage only the “Channel 1” control is enabled.

### Set Grid

To set the grid that displays all existing filters, click on the “Set Grid” node. see [Set Grid](#)

For some quick changes to the grid display see:

1. [Displaying/Hiding Columns](#)
2. [Resizing Columns](#)
3. [Changing Column Position](#)

To sort the grid see [Sorting Grid](#).

### Save Filter

None of the changes made to the filter settings are saved automatically. If you have changed any settings, the “Save” button will become enabled. If you wish them to take effect in the program, you must save them by clicking the “**Save**” button or the “**Enter**” key.

Shortcuts: **Ctrl+S** or **Enter**

#### *Warning:*

- *If you select another filter without saving changes, your modifications will be lost.*
- *If you close the dialog box without saving changes, you will get a warning and another opportunity to save your changes.*

### Delete Filter

To delete selected filter, select the filter from the drop down box and then the “**Delete**” button.

Shortcut: **Ctrl+Del**

You will get a warning from the system that the filter will be deleted permanently and the option to delete it or not. If you choose to delete it anyway, the filter will be deleted permanently.

### Cancel Changes

If you do not wish to save your changes to the filter and wish to return to all previous settings, you can cancel<sup>8</sup> all the changes at once by selecting the “**Cancel**” button.


Shortcut: **Ctrl+Q**

---

8) You can cancel only unsaved changes.

## Capcode Filter Type

In the “Filter By” control, select between:




1. Single – Enter a capcode into the “Enter Capcode” control – filtering criteria will be satisfied if a message contains the capcode entered .
2. Range – Enter the first capcode of the range into the “Capcode From” control and the last capcode of the range into the “Capcode To” control – filtering criteria will be satisfied if a message contains a capcode that that equals or falls between two capcodes..
3. Greater – Enter a capcode into the “Capcode Greater Than” control – filtering criteria will be satisfied if a message contains a capcode that is greater or equal to the entered capcode
4. Smaller– Enter a capcode into the “Capcode Smaller Than” control – filtering criteria will be satisfied if a message contains a capcode that is smaller than the entered capcode.

If the paging protocol you are using is "Pocsag" you can also set the Pocsag level criterion. Filtering criteria will be satisfied if the selected capcode criteria is satisfied and the capcode contains any of the Pocsag levels selected.

If you want the program to disregard the Pocsag level just uncheck all the boxes in the "Pocsag Level" group of controls.

## Text Filter Type

Enter a text string you are searching for in received messages into the “Search For” control. The string can be a single word, a phrase or several unrelated words.



Select a type of search in the “Find” control.

1. Any Word – filter criteria will be satisfied if any word from the search string is found in a message.
2. All Words – filter criteria will be satisfied only if all words from the search string are found in a message, but not necessarily in the same order.
3. Exact Phrase – filter criteria will be satisfied only if all words from the search string are found in a message and in the same order.

If you wish to have the search text to be case sensitive, check the “Case Sensitive” check box.

If you check the “Whole Words Only” check box, then the filter will look only for standalone words from the search phrase

E.g. the word “gun” would not be recognized in the word “gunmen”.


Otherwise, the filter will look for any partial match in any word in a message.

## Combo Filter Type

This filter type is a combination of the capcode and the text filter type. It allows the user to set any combination of the capcode and the text search and join them together in three logically different ways.

To set this filter, first set the capcode part in the same way as you would set the capcode filter type and then set the search text part in the same way as the text filter type.

You can then set a relation between each of these filter criteria by selecting a logical connection between them in the “Relation” control.



1. And – filtering criteria will be satisfied only if both the capcode and the text criteria are satisfied.
2. Or – filtering criteria will be satisfied if either (or both) the capcode and the text criteria are satisfied.
3. Either/Not Both – filtering criteria will be satisfied in the case when either (but not both) the capcode and the text criteria are satisfied.




## Export Filters

LogPage/Interceptor has an inbuilt facility that enables users to export their filter settings to other users. The user can set any number of filters and export them to a special type of file named "LogPage Filters File". For information on how to import that file into another LogPage/Interceptor application, see [Import Filters](#).

Select **'File|Export Filters'**.

Shortcut: **Ctrl+X**

Hot Keys: **Alt+F,E**



The "Export Filters" dialog shows all the filters that are defined in the application.

To exports the filters, select their name in the "Export Filters" control and click on the "Export" button.

Shortcut: **Ctrl+E**

In the "Save File" dialog, enter a file<sup>9</sup> name and press the "Save" button.

To get more information about any of the filters, select a filter and press the "View" button. see [View Filter Info](#)

Shortcut: **Ctrl+V**

---

9) You can save your filters only in the "LogPage Filters File" type of file. This file has the 'LFLT' extension


## Import Filters

LogPage/Interceptor has an inbuilt facility that enables users to import filter settings from other users. The user can import any number of filters from a special type of file named "LogPage Filters File". For information on how to export filters into that file, see [Export Filters](#).

Select **'File|Import Filters'**.

Shortcut: **Ctrl+I**

Hot Keys: **Alt+F,I**



To open a file<sup>10</sup> that contains exported filter specifications, select the "Find" button.

Shortcut: **Ctrl+F**

In the "Open File" dialog, select the file name and press the "Open" button.

The "Import Filters" box will show all the filters that are stored in the selected file.

To add these filters to the application, select desired filters, and press the "Import" button.

Shortcut: **Ctrl+I**

To get more information about any of the filters stored in the file, select a filter and press the "View" button. see [View Filter Info](#)


Shortcut: **Ctrl+V**

---

10) You can open only the "LogPage Filters File" type of file. This file has the 'LFLT' extension.


## View Filter Info

Displays summary of all settings for the selected filter. It can be accessed from the “[Edit Filter](#)” (see [Filter Summary](#)), “[Export Filters](#)” or “[Import Filters](#)” dialogs.



# Channels


## Set Channel

Select ‘Settings|Set Channel’ or click on the “Set Channel” toolbar button 

Shortcut: **Ctrl+C**

Hot Keys: **Alt+S,C**

### Interceptor



### LogPage and Interceptor Client



## Edit Channel

In the “Channel No” control select a channel that you wish to edit (**Interceptor only**)

Enter the channel title in the “Channel Title” text box (maximum 20 characters).

To turn the channel on/off and to turn other channel features on/off, check/uncheck their respective check boxes. For additional information see [Running Channels](#)


## Setting the Watchdog Alarm

The Watchdog Alarm is a function that alerts the user if and when a watchdog capcode (one that is transmitted on a regular basis) fails to be received during a set time interval. Only one alarm for only one capcode can be set per channel.

For details see [Set Alarm](#).

## Changing Channel Setups - Interceptor Only

In the Interceptor system, receiver settings are controlled by the Interceptor software.



The screenshot shows a window titled "Hardware Settings". Inside, there are two labels: "Frequency (MHz):" and "Protocol:". The "Frequency (MHz):" label is followed by a text input field containing the value "157.9250". The "Protocol:" label is followed by a dropdown menu currently displaying "Pocsag". Below these two fields is a button labeled "Apply" with a small yellow star icon to its left.

To change the Receiver Hardware channel frequency, enter a new value into the “Frequency” control. Value of the frequency must be entered in MHz.

To change the Receiver Hardware channel paging protocol, select appropriate value from the “Protocol” control.

Click the “Apply” button.

**Warning:** *You must save your changes, before you attempt to apply them.*

You will normally get a response message from the Receiver Hardware. If you get an error message, click the “Apply” button again. You can repeat this procedure until you get a success message.

If you notice that you are not receiving messages on a certain frequency, repeat above procedure.

You can set the frequency and paging protocol for all the channels at once, by selecting “[Hardware|Set Channels Hardware](#)” on the main form main menu. All channels will be set according to the above settings.

# Alarms

## Set Watchdog Alarm

The Watchdog Alarm is a feature of LogPage/Interceptor application that alerts the user to the failure of a specific capcode to be received in a given interval of time. This facility is used for network monitoring.

The user can set multiple alarms on every channel.

Every watchdog alarm is defined by a capcode and a monitoring interval. If the selected capcode does not appear in the selected time interval the application will raise an alarm. Whenever the capcode appears, it will reset the alarm timer to the beginning of the interval. It will also stop any previously raised alarm if it has not already been cancelled by the user.

The alarm can be additionally defined by one or more words that appear in the message. In that case the alarm will be raised if the selected capcode and predefined word(s) do not appear in the selected time interval

The alarm will be shown as a flashing icon on the toolbar, next to the channel number. It will be accompanied by a sound.

It can also bring up a popup form and send a page, email and SMS message to the designated users.


Select '**Settings|Set Channel**' and on the "Edit Channel" form select the "**Set Alarm**" button or select the "**Watchdog Alarm**" item on the channel menu.



In Interceptor you must also select a channel before selecting the Watchdog Alarm button

## Edit Alarm Dialog Layout

The “Edit alarm” dialog consists of three panels. The left panel is a tree-like list of all alarm settings available. The middle panel shows values for the selected setting. The right panel contains editing command buttons.



Selected Node (left panel)	Feature (middle panel)
<b>Alarms</b>	Displays all existing alarms and some of their setting values in the grid
<b>Selected Alarm</b>	Displays basic alarm settings
<b>Sound</b>	Alert sound settings for the selected alarm
<b>Paging</b>	Paging messages settings for the selected alarm
<b>Email</b>	Email messages settings for the selected alarm
<b>Mobile</b>	SMS messages settings for the selected alarm
<b>Popup Alert</b>	Popup alert form settings for the selected alarm

<b>Alarm Summary</b>	Displays summary of the selected alarm settings
<b>Alarm Display</b>	Settings for the channel alarm visual warning on the main form
<b>Set Grid</b>	Customizing grid that displays all existing alarms

## New Alarm

Click on the “**New**” button in the ‘Edit Alarm’ dialog box.

Shortcut: **Ctrl+N**

The “Selected Alarm” node becomes selected and the middle panel shows criteria for the new alarm.

Enter an alarm name in the “Alarm Name” box.

## Edit Alarm

### Selecting Alarm for Editing


Click on the “Alarms” node in the left panel to get the grid with all existing alarms displayed.

Select the alarm you wish to edit in the grid.



## Selected Alarm

Select the “Selected Alarm” node to get the panel with the basic alarm settings.



### Capcode<sup>1</sup>

Enter the alarm capcode that you are testing into the “Alarm Capcode” control.

### Message Text Search

If it is possible to receive pages from more than one transmitter per channel at the logging location, and all (or some) of the transmitters use the same capcode for their watchdog alarm message, you may change the content of the messages sent through each transmitter in order to identify the transmitter by the text contained in the message

In that case select the "Use Message Text" control in the "Identify Alarm by Message" group of controls. Enter a text string you are searching for in received messages into the “Search For” control. The string can be a single word, a phrase or several unrelated words. Select a type of search in the “Find” control.

1. Any Word – search criteria will be satisfied if any word from the search string is found in a message.

1) If you set the capcode to ‘zero’, the program will consider the alarm disabled.

2. All Words – search criteria will be satisfied only if all words from the search string are found in a message, but not necessarily in the same order.
3. Exact Phrase – search criteria will be satisfied only if all words from the search string are found in a message and in the same order.

If you check the “Whole Words Only” check box, then the alarm will look only for standalone words from the search phrase

E.g. the word “gun” would not be recognized in the word “gunmen”.

Otherwise, the alarm will look for any partial match in any word in a message.

### **Interval<sup>2</sup>**

Set alarm time interval, using the “Alarm Interval” group of controls.

This is the time the application will wait for the capcode to appear, before raising the alarm.

Maximum time is 240 minutes (4 hours) and 59 seconds.

### **Enable Alarm**

To enable the alarm check the “Enabled” check box. If this control is not checked, the program will disregard the alarm.


---

2) If you set the time to ‘zero’, the program will consider the alarm disabled.

## Alarm Sound

Select the “Sound” node to get the panel with the alarm sound settings.

Set alarm sound by entering values into the “Alarm Sound” group of controls. Every alarm on every channel may have a different sound associated with it.



You can create your custom sound or you can play a pre-recorded wave file. The difference is that, after the alarm is raised, the custom sound is played every repeat interval whilst the wave file will play only once.

Another difference is that the custom sound does not require a sound card. If you use a wave file, a sound card and speaker must be installed on the PC.

### Custom Sound

If you wish to create a custom sound, select the “Custom Sound” radio button.

Enter a value for the sound frequency (in Hertz) into the “Sound Frequency” control and sound duration (in milliseconds) into the “Sound Duration” control. These two values combined will create your custom sound.

### Wave File

If you want to use a pre recorded wave sound file, select the “Wave File” radio button.

To set your own wave file for the alarm, enter a path to a desired file into the “Wave File” control or press the “Find” button to use a usual Windows file search facility.

After you select a file the application will check that it is a correct sound file format. In the case of an incorrect file format, you will get an error message and the program will not allow you to use that file.

When the file is assigned to the alarm, you will see the length of the sound it contains, in the “File Length” control.

## Test Sound

To test your alarm settings, click the “Play” button. You do not have to save your settings to test them.

You will see the alarm icon flashing according to your [alarm display settings](#) and you will hear the selected sound. If you have selected a custom sound it will be repeated every repeat interval. The wave file will be played only once.

If you are not satisfied with your settings press the “Stop” button to stop the test, change your settings and test them again.

## Send Page Message

When the program raises the alarm, it can send a message to the designated pager numbers.

To set page messages for the selected alarm, select the “Paging” node. see “[Alerts – Pager Message](#)”

## Send Email Message

When the program raises the alarm, it can send an email message to the designated email addresses.

To set email messages for the selected alarm, select the “Email” node. see “[Alerts – Email Message](#)”

## Send SMS Message

When the program raises the alarm, it can send a text message to the designated mobile phone numbers.

To set SMS messages for the selected alarm, select the “Mobile” node. see “[Alerts – SMS Message](#)”

## Alarm Popup Form

When the program raises the alarm, it can also display a popup box to warn the user. Every alarm on every channel (Interceptor only) can be assigned its own popup alert, with basic information about the cause of the alarm.

To set a popup alert for the alarm, click on the “Set Popup Form” button. see [Alerts - Popup Alert](#)

## Alarm Summary


Displays summary of all settings for the selected alarm.

Shortcut: **Ctrl+I** or double-click on the alarm in the grid.



## **Alarm Display**

Sets display of the alarm visual alert on the main form. The alarm visual alert is set per channel and it is used for all alarms on one channel.



The user can set an image that will be displayed on the main toolbar next to the channel number when the watchdog alarm raises an alarm.

To achieve a flashing effect, the user needs to select two different images - "On Image" and "Off Image".

Select the image you want to set and select the "Find" button (shortcut: **Ctrl+F**). Use the windows "open file" feature to find a bitmap for the selected image type.

For the flashing effect you must enter a value in the "Flash Interval" control. The program will switch between bitmaps every selected interval. The interval is expressed in milliseconds. Maximum value is 2,000 ms (2 seconds) and minimum is 100 ms.

To see the effect use the "Start" button in the "Demo" group of controls. To stop the demo select the "Stop" button.

## Set Grid

To set the grid that displays all existing alarms, click on the "Set Grid" node. see [Set Grid](#)

For some quick changes to the grid display see:

1. [Displaying/Hiding Columns](#)
2. [Resizing Columns](#)
3. [Changing Column Position](#)



To sort the grid see [Sorting Grid](#).

## Save Alarm

None of the changes you make to the alarm settings are saved automatically. If you have entered some changes, the “Save” button will become enabled. If you wish them to take effect in the program, you must save them by clicking the “**Save**” button or the “**Enter**” key.

Shortcuts: **Ctrl+S** or **Enter**

**Warning:** *If you close the dialog box without saving changes, you will get a warning and another opportunity to save your changes.*

## Cancel Changes

If you are not satisfied with changes to the alarm and wish to return to all previous settings, you can cancel<sup>3</sup> all the changes at once by selecting the “**Cancel**” button.

Shortcut: **Ctrl+Q**

---

3) You can cancel only unsaved changes.

# Reports

## Using Report Tool

LogPage/Interceptor has an inbuilt reporting engine that allows the user to set report query values, to generate reports, display the results and save to a CSV file. Any report can be also set to be generated automatically by the program at the user's defined time interval and sent as an email attachment to the designated email address.

Select '**Reports|Reports**' or click on the "**Reports**" toolbar button to run the reporting engine 

Shortcut: **F8**


Hot Keys: **Alt+E,R**

The reporting software opens in a separate window and can be managed in parallel with the application. Running reports does not stop logging of messages and does not interfere with it in any way.

When the report engine opens, it will display an empty window and all existing report templates in the combo box on the toolbar. If there are no reports already created, you will see the text 'No Reports' in the combo.



You can also run the existing report directly from the main form.



Select “Reports” on the Main menu and select the report name from the drop down menu. The report engine will run that report, open the reporting software window and display the report result in a new window.

## Closing Report Tool

If you close the reporting tool the application will remember all open reports and their arrangement but only for the duration of the program session so you can later return to finish what you have started.


If you close the main program the reporting tool will be closed as well.

- [Set Report](#)
- [Run Report](#)
- [Save Report To File](#)
- [Report Window](#)

## **Set Report**

Most of the report functions are set up similarly to the filtering functions.






## Edit Report Dialog Layout

The “Edit Report” dialog consists of three panels. The left panel is a tree-like list of all filter settings available. The middle panel shows values for the selected setting. The right panel contains editing command buttons.

Selected Node (left panel)	Feature (middle panel)
<b>Reports</b>	Displays all existing reports and some of their setting values in the grid
<b>Selected Report</b>	Basic settings for the selected report
<b>Filter</b>	Criteria for the filter used in the report
<b>Colours</b>	Background and font colours for the selected report
<b>Email</b>	Email messages settings for the auto report
<b>Channels</b>	Channels that the selected report is valid for
<b>Report Summary</b>	Displays summary of the selected report settings

<b>Run</b>	Run selected report
<b>Report Window</b>	Settings for the window the report will be displayed in
<b>Set Grid</b>	Customizing grid that displays all existing reports

## New Report

To create a new report, select **'Report|New'** or click the **"New"** button on the toolbar 

You can also create a new report by selecting the "New" button, while in the "Edit Report" dialog.

Shortcut: **Ctrl+N**


Hot Keys: **Alt+R,N**

For setting report values see [Edit Report](#).

## Edit Report



To edit the report select it in the combo box on the toolbar.

Select **'Report|Edit'**, or click on the **"Edit"** button on the toolbar 

Shortcut: **Ctrl+E**

Hot Keys: **Alt+R,E**


Once the "Edit Report" form opens, you can change the report you are editing.

To change the report, click on the "Reports" node in the left panel to get the grid with all existing reports displayed.

Select the report you want to edit in the grid.

## Basic Settings

Select the “Selected Report” node to get panel with basic report settings.



Enter the name of the report into the “Report Name” control. Maximum number of characters is 30.

### Report Period

To select stored messages by their date, enter values into the “Report for Period” group of controls.

Select from the “Show Messages” between:

- **All Messages** – it will give you all messages that match [filtering criteria](#) below, regardless of their date.
- **Dates Between** – it will give you all messages that match [filtering criteria](#) below, that fall between dates selected in the “Date From” (inclusive) and “Date To” (inclusive) controls.
- **Dates Before** – it will give you all messages that match [filtering criteria](#) below, before date selected in the “Dates Before” (exclusive) control.
- **Dates After** – it will give you all messages that match [filtering criteria](#) below, after date selected in the “Dates After” (exclusive) control.



**Auto Report<sup>1</sup>**

LogPage/Interceptor can also create and send reports automatically.

To do so, check the “Enabled” control in the “Auto Report” group of controls.

If you wish your report to be created on a daily basis, select the “Daily” control, enter a day interval into the “Every” control and the time the report should be generated and sent into the “At” control.

If you wish your report to be created on an hourly basis, select the “Hourly” control, enter an hour interval into the “Every” control and the time the system should start to generate and send reports into the “Start At” control.

You must also set at least one valid email address for the auto report to work properly

**Sort Report<sup>2</sup>**

If you wish your report to be sorted in any particular order, select the "Enabled" check box in the "Sort Report" group of control.

Select a sort order in the "Sort Order" control to sort your report either in the ascending or descending order.


Select a field in the "Sort On Field" control on which values you want your report to be sorted.

---

1) When the auto report is enabled, the whole “Report for Period” group of controls are disabled, because the auto report engine does not use these settings. Every auto report is always generated for the period between two runs.  
2) If sorting is enabled it will be applied whether you run your report manually or automatically.

## Report Filter

Select the “Filter” node to get panel with the report filter criteria.



Select a filter type in the “Filter Type” control.


Depending on the filtering type selected, you will get different type of filtering controls.

1. [Capcode Filter](#)
2. [Text Filter](#)
3. [Combo Filter](#)

## Colours

Every report can be assigned a different background and font colour.

Select the “Colours” node to get the panel with the selected report colour settings.



Click on the “Fill” button and select a background colour for that report.

Click on the “Font” button and select a font colour for that report.

You can see how these colours match in the text box above the button.

## Email

When the auto report is created, it will be saved to a temporary file, and the report engine will generate email messages for every entered address, attach the file to the messages and remove the file from the hard drive afterwards.


To set email messages for the selected report, select the “Email<sup>3</sup>” node. see “[Alerts – Email Message](#)”

---

3) Email functionality for the selected report is enabled only when the [auto report](#) functionality is enabled.

## Channels

Select the “Channels” node to get the panel with the selected report channel<sup>4</sup> settings.



Select the channels that the report is enabled for.


---

4) In the LogPage application only the “Channel 1” control is enabled

## Report Summary

Displays summary of all settings for the selected report.

Shortcut: **Ctrl+I** or double-click on the report in the grid.



## Run

To run report immediately from the "Report Edit" form, select the "Run" node.

The "Report Edit" form will be closed and the report result will be shown in the new "Report Window"

## Report Window

To set the "Report Window" for all reports, select the "Report Window" node. see [Report Window](#) and [Set Report Window](#)

## Set Grid

To set the grid that displays all existing reports, click on the "Set Grid" node. see [Set Grid](#)

For some quick changes to the grid display see:

1. [Displaying/Hiding Columns](#)
2. [Resizing Columns](#)
3. [Changing Column Position](#)

To sort the grid see [Sorting Grid](#).

## Save Report

None of changes you make to the report settings are saved automatically. If you have entered some changes, the “Save” button will become enabled. If you wish them to take effect in the report, you must save them by clicking the “**Save**” button or the “**Enter**” key.

Shortcuts: **Ctrl+S** or **Enter**

### **Warning:**

- *If you select another report without saving changes, your modifications will be lost.*
- *If you close the dialog box without saving changes, you will get a warning and another opportunity to save your changes.*

## Delete Report

To delete selected report, select the “**Delete**” button.

Shortcut: **Ctrl+Del**

You will get a warning from the system that the report will be deleted permanently and the option to delete it or not. If you choose to delete it anyway, the report will be deleted permanently.


## Cancel Changes

If you are not satisfied with changes to the report and wish to return to all previous settings, you can cancel<sup>5</sup> all the changes at once by selecting the “**Cancel**” button.

Shortcut: **Ctrl+Q**

## Run Report

To run the report select it in the combo box on the report toolbar

Select ‘**Report|Run**’, or click on the “**Run**” button on the toolbar 

Shortcut: **F5**


Hot Keys: **Alt+R,R**

You can also run your report directly from the “**Edit Report**” form, by selecting the “**Run**” node.

After the reporting engine generates the report, result is displayed in a separate report window.

## Export Report To File

To save the report to a file, select the report from the combo box on the toolbar

Select ‘**File|Export to File**’, or click on the “**Export to File**” button on the toolbar 

Shortcut: **Ctrl+S**

---

5) You can cancel only unsaved changes.

Hot Keys: **Alt+F,E**


In the “File Save” dialog box enter the file name in the “File Name” control (you do not need to enter a file extension) and press the “Save” button or the “Enter” key.

All files are saved as Comma Separated Values (CSV) files which may be opened in a spreadsheet or database application .


## Report Window

After you create the report, the result will be displayed in a grid in a new window, and its name will be selected in the combo box on the toolbar.

You can run multiple reports at the same time. They will be opened as separate windows within the report generator.




To select displayed report, either click on it or select its name in the combo box on the toolbar, or go to 'Window' and select its name from the list of opened reports. Its window will become focused (even if it was minimized).

To close a focused report, select '**Report|Close**', or click on the "**Close**" button on the toolbar 

Shortcut: **Ctrl+W**

Hot Keys: **Alt+R,C**

To close all opened reports, select '**Reports|Close All**', or click on the "**Close All**" button on the toolbar 


Shortcut: **Ctrl+A**

Hot Keys: **Alt+R,A**



## Arranging Reports

You can arrange all open reports in different ways to make them more accessible.



- Select **'Window|Tile Vertical'** to arrange them as vertical tiles.
- Select **'Window|Tile Horizontal'** to arrange them as horizontal tiles.
- Select **'Window|Cascade'** to arrange them in a cascading order.
- Select **'Window|Minimize All'** to minimize all reports.
- Select **'Window|Arrange All'** to arrange **icons** of the **minimized** reports.

## Set Report Window

To set the way your reports will be displayed, select the "Report Window" button 

Shortcut: **F2**

All above command will open [Set Grid](#) dialog.

It will enable you to set:

- Report background colour (default for all reports)
- Report columns to be displayed, their title, width and position
- Report font type, size and colour

All above settings will be used as a template for all reports created in future.

If you have some reports already displayed, their settings will be changed accordingly.

You can also access these settings from the ["Set Reports"](#) dialog, by selecting the "Report Window" node

To make some quick changes to the displayed report, see:

1. [Displaying/Hiding Columns](#)
2. [Resizing Columns](#)
3. [Changing Column Position](#)

All those changes will be stored automatically and used as a template for all reports created in future, but they will not affect other currently displayed reports.

## **Sorting Displayed Report**

Displayed report data can be sorted on every column in ascending or descending order.

To sort a grid column, just click on its title. Every time you click it will toggle between ascending and descending sorting order.

If you want more control over the sorting order, right click on the column title and select the "Sort Ascending" or the "Sort Descending" item from the popup menu.

# Alerts

## Popup Alert

The popup alert is a form that pops up when the program meets some filter criteria or raises an alarm. It contains some basic data about the filter or the alarm that invoked it. The user can choose whether or not to display that form for the filter or the alarm event.

Setup for this form is accessible from the “[Edit Filter](#)” or “[Edit Alarm](#)” form. It can be set for every filter or alarm separately.

On any of these forms select the “**Popup Alert**” node.

**LogPage - Edit Popup - for filter "Test Capcode"**

☒ **Popup Enabled**

Popup Caption:

**Popup Intervals**

Flash Interval (ms):  ☒ **Flash**

Popup Timeout (s):

**Show on**

☒ **Filter Hit** ☐ **Traffic Monitor Hit**

**Popup Dimensions**

Popup Width:  Popup Height:

**Display**

**Message Format**

Filter: <Filter Name>  
Filtering criteria: <Filter Criteria>  
Date: <Date/Time>  
Message: <Message Text>

Variable Fields:

## Enable Popup Alert

For popup alert to appear, you must enable it by checking the “Popup Enabled” control.

## Show On Option (Filter Only)

To display the popup alert on every filter hit, select the "Filter Hit" control in the "Show On<sup>1</sup>" group of controls.

To display the popup alert on every traffic monitor hit, select the "Traffic Monitor Hit" control in the "Show On" group of controls.

## Popup Form Caption

To set the popup form caption, enter a value into the "Popup Caption" control.

The caption will be displayed in the form:

"<program\_name> – <user\_caption>"

For example, if the user enters "Test Filter" into the "Popup Caption" control, form caption will be: "LogPage – Test Filter".

## Popup Dimensions

A width and a height of the popup form can be set by entering values into the "Popup Width" and "Popup Height" respectively. These values are expressed in pixels.

An easy way to set dimensions is through the test form. see [Testing](#)

## Popup Colour

Every popup form can be assigned different background colour.

Click on the "Colour" button and select a background colour for that popup.

Shortcut: **Ctrl+C**

Hot Keys: **Alt+C**

The new selection will display in the text box above the button.

## Popup Font

Click on the "Font" button.

Shortcut: **Ctrl+F**

Hot Keys: **Alt+F**

In the Font Dialog you can select a font type from the "Font" control. You can use any font that is installed on the machine.

You can also select a font size (from the "Size" control) and a font colour (from the "Color" control) and any font style (bold, italic, strikeout, underline).

All changes to the font will display in the text box above the button.

---

1) The "Show On" group of controls ("Filter Hit" and "Traffic Monitor Hit") is displayed only during the filter setup.

## Flashing

To make the popup form to flash (blinking caption), check the “Flash” control.

You can also set a flashing interval by entering a value into the “Flash Interval” control. Values are expressed in milliseconds<sup>2</sup>.

If you do not know the value to enter, try different values and playing with the test form. see [Testing](#)

## Timeout

To set how long the popup form will be displayed, enter appropriate value into the “Popup Timeout” control. This value is expressed in seconds and defines the number of seconds the pop up will be displayed.

If you enter ‘zero’ for the value, the popup form will stay on the screen until closed by the user.

## Message

You can create the whole text the popup alert form will display and format it any way you like. see [Set Alert Message](#)

## Testing

To test your settings, click on the “Test” button. You will see an example of the popup form with your current settings.

You do not need to save settings to test them.



You can also use this test form to setup width and height easily. Just resize the form with your mouse pointer, and when you close it the “Popup Width” and “Popup Height” controls will assume the width and the height of the test form.

---

2) 1000 ms = 1 sec

## Save Popup

Changes you make to the popup settings are not saved automatically. If you have made some changes, the “Save” button will become enabled. If you wish them to take effect in the program, you must save them by clicking the “**Save**” button or the “**Enter**” key.

Shortcuts: **Ctrl+S** or **Enter**

*Warning: If you close the dialog box without saving changes, you will get a warning and another opportunity to save your changes.*

## Cancel Changes

If you are not satisfied with changes to the popup form and wish to return to all previous settings, you can cancel<sup>3</sup> all the changes at once by selecting the “**Cancel**” button.

Shortcut: **Ctrl+Q**

---

3) You can cancel only unsaved changes.

## Pager Message


The program can send a page message to the designated pager numbers when:

- the program finds a message that matches filtering criteria (filter hit)
- a filter hit occurs a certain number of times in a certain time interval (traffic monitor hit)
- the program raises an alarm

On the “[Edit Filter](#)” or “[Edit Alarm](#)” dialog select the “Paging<sup>4</sup>” node to bring up the paging settings for the selected filter or alarm.

---

4) When you select the “Paging” node, all editing controls in the right hand panel (buttons “New”, “Cancel”, “Delete”) refer to the paging functionality not to the selected filter or alarm.



Click on the “**New**” button to add a pager number to the list.

To delete the number from the list, select it and click the “**Delete**” button.

The messages to be sent to each pager can be individually tailored for each Pager ID.

To create or edit the page message for the respective pager number select the pager number in the “Pager ID” box.

To send the message to that pager ID on every filter hit, check the "Filter Hit" box.

To send the message to that pager number on a traffic monitor hit, check the "Traffic Monitor Hit" box.

**Warning:** *If the "Traffic Monitor Hit" box is checked, you must also enable the filter traffic monitor and enable paging on the "Traffic Monitor" page to send Traffic Monitor messages.*

Edit the message to be send in "Message Format". see “[Set Alert Message](#)”

To test the formatting result, select the “**Show**” button.

For a complete test (sending formatted message with test data to the selected pager ID), select the



“**Send**<sup>5</sup>” button.

To enable paging for the selected filter or email check the “Paging Enabled” box.

All pager numbers are checked to ensure they are valid pager numbers.

LogPage/Interceptor does not impose any limits on the number of pagers assigned to the filter or alarm.

---

5) Before you attempt to send the test page, be sure that the paging functionality is set and enabled for the whole application. see [Set Paging](#)

## Email Message


The program can send an email message to the designated email addresses when:

- the program finds a message that matches filtering criteria (filter hit)
- a filter hit occurs a certain number of times in a certain time interval (traffic monitor hit)
- the program raises an alarm
- the program creates an auto report

On the “[Edit Filter](#)”, “[Edit Alarm](#)” or “[Edit Report](#)” dialog select the “Email<sup>6</sup>” node to bring up the email settings for the selected filter, alarm or report.

---

6) When you select the “Email” node, all editing controls in the right hand panel (buttons “New”, “Cancel”, “Delete”) refer to the email functionality not to the selected filter, alarm or report.



Click on the “**New**” button to add an email address to the list.

To delete the email address from the list, select it and click the “**Delete**” button.

Enter an email subject into the “Email Subject” box.

The body of the email message may be set individually for each email address. To create or edit an email message for the respective email address, select the address in the “Email Address” box.

To send the message to that email address on every filter hit, check the "Filter Hit" box.

To send the message to that email address on the traffic monitor hit, check the "Traffic Monitor Hit" box.

**Warning:** *As well as selecting the "Traffic Monitor Hit" control, you must also enable the filter traffic monitor and enable email in the "Traffic Monitor" page.*

Edit message as described in “[Set Alert Message](#)”

To test formatting result, select the “**Show**” button.

For a complete test (sending formatted message with test data to the selected email number), select the “**Send**” button.

7) Before you attempt to send the test email, be sure that the email functionality is set and enabled for the whole

To enable email for the selected filter or alarm check the “Email Enabled” box on the respective dialog.. Email functionality for the selected report is automatically enabled when the [auto report](#) functionality is enabled.

All email addresses are checked to ensure they are properly formatted email addresses.


LogPage/Interceptor does not impose any limits on the number of email address assigned to the filter, alarm or report. You should be aware that sending to many email messages at once may be a burden on your SMTP server and it may not be able to process them. If you are not sure about this discuss with your network administrator.

## SMS Message

The program can send a an SMS message to the designated mobile phone numbers when:

- the program finds a message that matches filtering criteria (filter hit)
- a filter hit occurs a certain number of times in a certain time interval (traffic monitor hit)
- the program raises an alarm

On the “[Edit Filter](#)” or “[Edit Alarm](#)” dialog select the “Mobile”<sup>8)</sup> node to bring up the SMS settings for the selected filter or alarm.



Click on the “**New**” button to add a mobile phone number to the list.

To delete the number from the list, select it and click the “**Delete**” button.

8) When you select the “Mobile” node, all editing controls in the right hand panel (buttons “New”, “Cancel”, “Delete”) refer to the SMS functionality not to the selected filter or alarm.

To create or edit an SMS text message for the respective mobile phone number, select the number in the “Phone Number” box

To send the message to that mobile number on every filter hit, check the "Filter Hit" box.

To send the message to that mobile number on a traffic monitor hit, check the "Traffic Monitor Hit" box.

**Warning:** *As well as selecting the "Traffic Monitor Hit" control, you must also enable the filter traffic monitor and enable SMS on the "Traffic Monitor" page.*

Edit message as described in “[Set Alert Message](#)”

To test formatting result, select the “**Show**” button.

For a complete test (sending formatted text message with test data to the selected mobile phone number), select the “**Send**” button.

To enable SMS messaging for the selected filter or alarm check the “SMS Enabled” box on the respective dialog.

All mobile phone numbers are checked to ensure they are valid phone numbers.

LogPage/Interceptor does not impose any limits on the number of mobile phone numbers assigned to the filter or alarm.

---

9) Before you attempt to send the test SMS message, be sure that the SMS functionality is set and enabled for the whole application. see [Set SMS](#)

## Set Alert Message

The alert message is a message that is presented to the user after a system event. That event could be a filter hit, an occurrence alert, raising of the watchdog alarm or sending an auto-report. The message could be an email message, a pager message, a SMS message, a popup alert message or a message logged into a file. All of them share the same characteristics and they are created and edited in the same way.

The message is a combination of literal text entered by the user and variable fields filled in by the system.

For example:

Formatted message:


Filter alert for the "<Filter Name>" on <Date/Time> with message: "<Message Text>"

Final result:

Filter alert for the "Test Filter" on 02/02/07 10:05:01 with a message: "Popup test message for "Test Filter" filter"

In this example the filter name value is "Test Filter", the event happened on 02/02/2007 at 10:05:01 am and that the message content was "Popup test message for "Test Filter" filter"

The message editing tool comprises a large area for entering a text (titled "Message Format"), the "Variable Fields" combo box for selecting available variable fields and the "Add" button for adding selected variable field to the text.



To create a message

1. Enter the text that you wish to appear in the message.
2. Position the cursor where you want a variable field to appear in the text.
3. Select a field in the "Variable Fields" control.
4. Click on the "Add" button.

Steps 3 and 4 can be replaced by right-clicking into the editing control and selecting the field name from the popup menu.



The name of the field appears in the text, surrounded by tags (e.g. <field\_name>). Leave it as it is because those tags tell the system that it is dealing with the field name and that it has to replace that name with the current system value.

You can also type the whole message (including variable fields) directly. But you must be aware of few things:

- ✓ You can use only field names displayed in the “Variable Fields” control
- ✓ Spelling must be correct (including spaces)
- ✓ Field name must be surrounded with tags
- ✓ Case does not matter

The system will honour any space or new line that you have entered, so you can format the message any way you like.

If the tool is part of the email editing tool, you can use it to create the email subject field in the same way. Just position the cursor into the "Email Subject" control instead.

You can also see how your message will look like with real data entered.

Select the button with “Test” or “Show” caption (depending on dialog box you are using) and the whole message, with variable fields replaced by test data, will popup in a separate window.

You do not need to save your message format before testing.



# Grids

## Set Grid

LogPage/Interceptor displays two types of grids:

1. **Main grids** – displayed in the main application window (Active and Paused grid)
2. **Auxiliary grids** – used inside different setting dialogs (Filter, Report and Alarm grid)


Both of these types can be set in the same way. The only difference is in the way you run their settings dialog.

To run grid settings dialog for the Main grids

Select **'Settings|Set Grid'**

Shortcut: **Ctrl+G**

Hot Keys: **Alt+S,G**



Or right-click on the grid title and from the popup menu select **'Set Grid'**





In the “Select Grid” control select the grid that you wish to edit.

There are two grids to choose from:


- **Active** grid – settings applied when you start or stop logging of messages.
- **Paused** grid – settings applied when you pause logging of messages.

To run the grid settings dialog for the Auxiliary grids see [Set Filter Grid](#), [Set Report Grid](#), [Set Report Window](#) and [Set Alarm Grid](#).

## New Field (Column)

The number of fields that you can create in LogPage/Interceptor is limited by the number of distinct information that is available from the logged message. The application will warn you if you set two columns to show the same type of data.

All of the types of data that can be displayed for each message are listed in the “Displays Value for” combo box.




To create a new field, press the “New” button.

Shortcut: **Ctrl+N**

By default the application will create a field with the next available type of data and suggest an appropriate name for the field.

In the popup dialog enter a name for the new field and click “OK”.



The name may be up to 30 characters long and it may consist of one or more words. It can contain any printable character. If the name is longer than 30 characters, it will be truncated. This name will be displayed as a column title on the grid title bar

### **Edit Field**

In the “Fields” control select the field you wish to edit.

#### ***Changing field position***

The “Fields” control shows fields on the same position as in the grid title. Click on the “Up” or “Down” button to move the field up or down until you are satisfied with its position. See Grid Display/Changing Column Position

These changes are saved automatically. If you have the respective grid opened, you will see the changes immediately.

#### ***Changing field title***

Click on the “Change Title” button. In the popup dialog enter a new name for the selected field and click “OK”. (for naming see [New Field](#))

Those changes are saved automatically. If you have the respective grid opened, you will see the changes immediately.

#### ***Showing/Hiding Fields***

Check or uncheck the “Field Visible” check box. Its respective icon in the “Fields” control will change accordingly. See Grid Display/Displaying/Hiding Columns

This change is **not saved** automatically.

### Changing Field Width

Enter desired field width into the “Field Width” control. The field width is expressed in pixels. If you do not feel comfortable working with pixels, see Grid Display/Resizing Columns.

This change is **not saved** automatically.

### Changing Display Data Type

Each field displays data obtained for each message received. You can change which data each field displays by selecting from the “Displays Value for” combo box.

If you try to set two fields to display the same data, you will get a warning message.

This change is **not saved** automatically.

### Save Field

If you have entered some changes into the field that are not saved automatically, the “Save” button will become enabled.

To save changes to the field, press the “**Save**” button or the “**Enter**” key.

Shortcuts: **Ctrl+S** or **Enter**

#### **Warning:**

- *If you select another field, without saving changes to the previously selected field, the modifications to that field will be lost.*
- *If you select another grid without saving changes, you will get a warning and another opportunity to save your changes.*
- *If you close the dialog box without saving changes, you will get a warning and another opportunity to save your changes.*

### Delete Field

In the “Fields” control, select the field you wish to delete.

Select the “**Delete**” button.

Shortcut: **Ctrl+Del**

You will get a warning from the system that the field will be deleted permanently and the option to delete it or not. If you choose to delete it anyway, the field will be deleted permanently and removed from the grid, with all its data, instantly.

Deleting a field from the display does not affect logging messages permanently into the database.

**Warning:** *Deleting is not the same as hiding a field.*

## **Grid Display**

### ***Grid Default Colour***

Grid default colour will be used as a background colour for messages that are not filtered (on the Main grids) or if the user selects the “[Use Grid Colours Only](#)” control.

Click on the “Colour” button and select default background colour for that grid.

Shortcut: **Ctrl+C**

Hot Keys: **Alt+C**

The new selection will display in the text box above the button.

### ***Use Grid Colours Only***

If this control is checked, the grid display engine will ignore all other colour settings (filter colours, report colours, etc.) for that grid and use only grid default background and font colours.

### ***Word Wrap***

If this control is checked, the grid display engine will force all text to fit within the defined margins of the grid cell. If the length of the text is greater than the width of the cell, the text will be split and placed into the next line and the height of the cell (and the whole grid row) will be increased accordingly. This process will continue until the whole text is displayed within the grid cell. No word will ever be split between two lines. Word wrap will also occur after the user changes the margins of the grid manually.

Word wrap feature does not change content of the original text displayed in the cell.

### ***Grid Font***

Click on the “Font” button.

Shortcut: **Ctrl+F**

Hot Keys: **Alt+F**

In the Font Dialog you can select a font type from the “Font ” control. You can use any font that is installed on the machine.

You can also select a font size (from the "Size" control) and a font colour (from the "Color" control).

A font style (bold, italic, strikeout, underline) is not supported by the grid display engine and it will not change the grid display.

All changes to the font will display in the text box above the button.

### ***Vertical Margins***

The "Vertical Margins" control allows the user to set margins between the text in the grid and the grid cell top and bottom edges. This feature works only when the "[Word Wrap](#)" feature is turned off. The value is expressed in pixels and default value is 4.

## Save Grid Display

To save grid display changes, press the “**Save**” button or **Enter** key.

Shortcuts: **Ctrl+S** or **Enter**

## Cancel Changes

If you are not satisfied with changes to the field and wish to return to all previous settings, you can cancel<sup>1</sup> all the changes at once by selecting the “**Cancel**” button.

Shortcut: **Ctrl+Q**

## Quick Setup

### Displaying/Hiding Columns

Right-click on any of the message grid column headings to bring up a popup menu that shows the names of all columns created for that grid and in the same order as they are displayed in the grid. All visible columns have a check mark next to they name.



To hide a visible column or to show a hidden column, click on its name on the popup menu.

### Resizing Columns

Move the mouse pointer to the grid title bar.

Position the mouse over the edge of the column you wish to resize. The mouse pointer cursor

---

1) You can cancel only unsaved changes.

changes into the resizing cursor.

Hold the main mouse button down and resize the column by moving the mouse pointer.

## Changing Column Position

Move the mouse pointer to the grid title bar.

Position the mouse over the column you wish to move. Click and hold the main (left) mouse button and drag the column to the new position you wish it to appear.

Capcode	Capcode Id	Protocol	Level	Date/Time	Filters	Message Text
2389335	Demo	Pocsag	A	11/06/2008 10:26:31	None	The passageway leading to Nearly Headless Nick's p
1961326	Demo	Pocsag	A	11/06/2008 10:26:30	Text Filter	Harry was at the point of telling Ron and Hermione
1234567	Demo	Pocsag	B	11/06/2008 10:26:30	Capcode Filter	Rain was still lashing the windows, which were now
2437208	Demo	Pocsag	A	11/06/2008 10:26:30	Text and Capcode Filter	"A promise is a promise," Hermione reminded Harry
1597275	Demo	Pocsag	C	11/06/2008 10:26:30	Text Filter	So at seven o'clock, Harry, Ron, and Hermione walk
2150453	Demo	Pocsag	C	11/06/2008 10:26:29	Text Filter	Nearly Headless Nick beamed at him. "A deathday p
1069010	Demo	Pocsag	B	11/06/2008 10:26:29	Text Filter	"Of - of course," said Harry.
1841906	Demo	Pocsag	A	11/06/2008 10:26:29	None	"Why would anyone want to celebrate the day they
2118932	Demo	Pocsag	D	11/06/2008 10:26:28	Text Filter	"My dear boy! Harry Potter, at my deathday party! A
1334037	Demo	Pocsag	B	11/06/2008 10:26:28	Text Filter	"No," said Harry quickly, "I'll come -"
2902197	Demo	Pocsag	B	11/06/2008 10:26:28	None	"I'm holding a party down in one of the roomier dur
2693187	Demo	Pocsag	D	11/06/2008 10:26:27	Text and Capcode Filter	"Oh," said Harry, not sure whether he should look s
2029488	Demo	Pocsag	C	11/06/2008 10:26:27	None	"Well, this Halloween will be my five hundredth dea
2574308	Demo	Pocsag	D	11/06/2008 10:26:27	Text and Capcode Filter	"What is it?" said Harry.
1603195	Demo	Pocsag	A	11/06/2008 10:26:26	Text Filter	Nearly Headless Nick stopped in his tracks and Harry

You can do all above changes while the application continues to receive messages. All changes will be stored and retrieved next time you open LogPage/Interceptor.

The application differentiates between grids displayed in the **active** and **paused** mode, so you can have different grid settings for each of them.

## Sorting Grid


Displayed grid data can be sorted on some columns (where it make sense) in ascending or descending order.

Only auxiliary grids can be sorted.

To sort a grid column, just click on its title. If the column is sortable, every time you click on it, it will toggle between ascending and descending sorting order.

If you want more control over the sorting order, right click on the column title and select the "Sort Ascending" or the "Sort Descending" item from the popup menu.





If those items are disabled, that means that the selected column is not sortable.

# Demo


## Set Demo

LogPage/Interceptor has an inbuilt demonstration facility that emulates the incoming messages of the Receiver Hardware for testing and training purposes.

Select **'Settings|Set Demo'**.

Shortcut: **Ctrl+D**

Hot Keys: **Alt+S,D**



The demo facility uses a stored text file to generate the messages. To change the file, press the “Find” button. You may select any text (TXT) file. The system will parse and format it to produce messages.

If you wish demo messages to be saved (e.g. for testing the database or reports), check the “Save Demo Messages” check box. It is recommended that these messages are deleted before you start to run the application for real message logging. see [Messages - Delete Messages Permanently](#)

The demo engine parses the selected file into file lines (on the line break character). The user can select a number of file lines that will make up a demo message (minimum = 1; maximum = 5).

Messages will be created and displayed on a set time interval. To set the interval between messages, enter a value into the “Msg Time Delay” control. Values are expressed in milliseconds (1 second = 1,000 milliseconds).

Every message has a channel number. You can generate channel numbers sequentially (1,2,3,4) or randomly. Select appropriate value in the “Generate Channel Numbers” group of controls. (Interceptor only). The LogPage demo engine will only generate messages on channel 1.

The demo engine will always generate a capcode for every message. You can set the range that capcodes will be selected from. Enter capcode value for the start of the range into the “From” control and for the end of the range into the “To” control. Capcodes will be selected within that range randomly.

The demo facility can be also used to test the watchdog alarm feature. see [Watchdog Alarm](#)

Enter an alarm capcode into the "Alarm Capcode" control and the demo engine will generate the message with that capcode for every interval value entered into the "Interval" group of controls. Interval values are entered in minutes and/or seconds (max value is 180 min and 59 sec). If the interval value is set to 'zero', the message with the alarm capcode will not be created.

To run the demo program see “[Run Demo](#)”.

## Save Demo

Changes to values are not saved automatically

If you wish to save them press the “**Save**” button or the “**Enter**” key.

Shortcuts: **Ctrl+S** or **Enter**

**Warning:** *If you close the dialog box without saving changes, you will get a warning and another opportunity to save your changes.*

## Cancel Changes

If you are not satisfied with changes to the demo and wish to return to all previous settings, you can cancel<sup>1</sup> all the changes at once by selecting the “**Cancel**” button.

Shortcut: **Ctrl+Q**

---

1) You can cancel only unsaved changes.

# Shortcuts

<b>User</b>	
Log on as different user	Ctrl+L
Set your account	Ctrl+A
Change password	Ctrl+P
<b>File</b>	
Export Filters	Ctrl+X
Import Filters	Ctrl+I
Exit	Alt+F4
<b>Display</b>	
Show/Hide Toolbar	Shift+Ctrl+T
Show/Hide Status Bar	Shift+Ctrl+S
Show/Hide Full Message	Shift+Ctrl+M
Show Full Screen	Ctrl+PgUp
Show Normal Screen	Ctrl+PgDown
<b>Run</b>	
Run	F5
Run Demo	Ctrl+F5
Stop	F6
Pause/Resume	Ctrl+F6
Open Report Tool	F8
<b>Messages</b>	
Clear Display	Ctrl+F2
Delete All Messages	Shift+Ctrl+Del
Delete Old Messages	Ctrl+Del
Refresh Display	Ctrl+F3
Copy Selected Message	Shift+Ctrl+C

Go To First Row	Home
Go To Next Row	Right or Down Arrow
Go To Last Row	End
Go To Previous Row	Left or Up Arrow
<b>Settings</b>	
Set System	Ctrl+S
Set User	Ctrl+U
Set Filter	Ctrl+F
Set Grid	Ctrl+G
Set Channel	Ctrl+C
Set Demo	Ctrl+D
<b>Channel</b>	
<i>Interceptor</i>	
Channel (1,2,3,4) On/Off	Ctrl+(1,2,3,4)
<i>LogPage</i>	
Channel On/Off	Ctrl+1
<i>Interceptor</i>	
Stop Alarm On Channel (1,2,3,4)	Shift+Ctrl+F(1,2,3,4)
<i>LogPage</i>	
Stop Alarm On Channel 1	Shift+Ctrl+F1
Stop Alarm On All Channels	Ctrl+Space
<b>Edit Dialogs</b>	
New	Ctrl+N
Delete	Ctrl+Del
Cancel	Ctrl+Q

Save	Ctrl+S or Enter
Close	Escape
<b>Report</b>	
Run Report	F5
New Report	Ctrl+N
Edit Report	Ctrl+E
Export Report to File	Ctrl+S
Close Report Window	Ctrl+W
Close All Reports	Ctrl+A
Set Report Window	F2
<b>Filter Export/Import Dialog</b>	
Export To File	Ctrl+E
Find Filter File	Ctrl+F
View Selected Filter	Ctrl+V
Import From File	Ctrl+I
Close	Escape